

802.11b/g /n USB Dongle

Model #

AWLL6077 V2 ;

WUB1920RS ;

WV-120N ;

UW-200NU2 ;

BS-WN-USB/1

User's Manual

Table of Contents

1. Introduction	4
1.1 Package Contents	4
1.2 Features	4
2. Installation	5
3. Configuring the Adapter	11
4. Wireless Utility	17
4.1 Wireless Information	17
4.2 AP List	18
4.3 Profile Settings.....	19
4.4 Configuring Encryption	21
4.5 Ad-hoc and Peer-to-Peer Wireless Networks	27
4.6 Wi-Fi Protected Setup (WPS)	30
4.7 SoftAP.....	30
4.7 About	38
Appendix A – Features	39
Appendix B – Information	40
Technical Support	41

1. Introduction

Congratulations on your purchase of the Wireless N USB Adapter. Its high bandwidth combined with extended wireless coverage delivers fast and reliable connection for all of your networking applications when used with other Wireless N products.

A full range of security features such as WEP, WPA-PSK, and WPA2-PSK provide the highest level of wireless network security. The bundled Wireless Utility allows you to set up the adapter with an easy-to-use user interface. Best of all the Wireless N USB Adapter works with 802.11g and 802.11b network devices ensuring compatibility with your existing wireless products.

1.1 Package Contents

Before you begin the installation, please check the items of your package. The package should include the following items:

- WUB1920RS Wireless N USB Adapter
- USB Cable
- Quick Installation Guide
- Installation CD (Driver/Utility/Manual)

1.2 Features

- Industry's highest wireless data rate with IEEE 802.11n draft specification 2.0
- 64-bit/128-bit WEP encryption, Pre-shared Key (PSK), and Wi-Fi Protected Access (WPA2 and WPA) support provide full protection for your wireless connection
- Higher data rate increases the reliability and stability of wireless connections
- Great for environments with higher wireless data traffic requirements
- Fully backward-compatible with 802.11b/g devices
- Works best with other Wireless N products

2. Installation

This section provides instructions on how to install the **WUB1920RS Wireless N USB Adapter**. The driver is installed along with the utility.

Step 1 Insert the USB adapter into an available USB port and turn on your computer.

Step 2 After turning on the computer, Windows will launch the **Found New Hardware Wizard**. The Found New Hardware Wizard appears differently depending on your operating system. Click **Cancel** to quit the wizard and insert the Installation CD into your CD drive.






Step 3 The Autorun screen will pop up. Select **Install Utility and Driver** from the menu.



Note: If the Autorun screen doesn't appear automatically, or if you get a blank white screen, go to **Start, Run,** and type **D:\Utility\Setup.exe** (where **D** is the letter of your CD drive) and click **OK**.


Windows Vista users: At this point, you may get a warning message like the one below. Make sure that you click **Allow** to continue with the installation.




Step 4 Click **Next** at the welcome screen.




Step 5 Click **Install** to begin install.







Step 6 Click **Continue Anyway** at the Windows Logo Screen. (For Windows 2000, click **Yes** at the Digital Signature Not Found prompt).



For Windows Vista, click the **Install this driver software anyway** button when the security warning appears.



Step 7 Click **Finish**.



3. Configuring the Adapter

This section describes how to connect your wireless adapter to a wireless network.


Note to Windows XP Users:

You must disable the Wireless Zero Configuration Utility in order to use the bundled Wireless Utility. Please follow the steps below to disable XP's wireless utility. Windows Vista users can skip the following instructions and go to **Step 1**


Double-click on the **Wireless Network Connection Icon** in the system tray and then click on **Properties** or **Advanced**.




When the new wireless network connection properties window appears, go to the **Wireless Networks** tab, uncheck the **“Use Windows to configure my wireless network settings”** check box and click **OK**.




Step 1 To open the utility, double click on the Wireless Monitor icon in the system tray at the bottom right-hand corner of your screen.



Step 2 Go to the **Available Network** tab, select the **SSID** (Network Name) of the wireless network you wish to connect to, and double click **Add to Profile**.



If the network you are attempting to connect to is configured for encryption, you will see an orange lock icon next to the network.



When you click on it and click connect, a box will pop up requesting the wireless encryption key for the router. Enter the encryption key into the box and click **OK**.

Wireless Network Properties:

Profile Name:

Network Name(SSID):

This is a computer-to-computer(ad hoc) network; wireless access points are not used.

Channel: 1 (2412MHz)

Wireless network security
This network requires a key for the following:

Network Authentication: Open System

Data encryption: Disabled

ASCII PASSPHRASE

Key index (advanced): 1

Network key:

Confirm network key:

802.1x configure

EAP TYPE : GTC

Tunnel : Privision Mode :

Use saved user credential

Username :

Identity :


Domain :

Password :

Certificate :

PAC : Auto Select PAC

Step 3 You should now be connected. You should see “Status” in the top, middle, and SSID, signal Strength, Link Quality.



Troubleshooting: If you are experiencing problems with the connection (unable to connect, low signal strength, slow connection speed, not working, unstable wireless connection) you will want to tune your router’s signal by changing channels on the router.

You do not need to change the channel on the card, it will automatically pick up the new channel after you reboot. The only channel that you need to change is the router’s channel.

Your router has 11 different channels to choose from. Start with channel 1 and work your way up. Each time you change the channel on the router, make sure that you restart the wireless computer before trying to connect again. Keep going through the channels until you find one that gives you a stable connection.


For instructions on changing channels, refer to the documentation that came with your router.

4. Wireless Utility

This section describes the various functions of the Wireless Monitor that you can configure, including the settings of wireless encryption.


4.1 General

The **General** box, you with the status of the current connection, including status, speed, type, encryption, network name (SSID), signal, link quality, and Network Address (MAC Address, IP Address, Subnet Mask, Gateway).



4.2 Profile Settings

This section provides instructions on using the **Profile** section of the wireless monitor.



The **Available Profile(s)** box lists the different profiles you've created for the different networks that you use. Profiles are automatically created and added to this list when you connect to new networks. You can also manually add profiles.

To modify an existing profile, select that profile from the **Available Profile(s)** box and click on **Edit**.

To create a new profile, click on **Add**.

The **Profile** box will appear allowing you to specify the settings for your new profile or change settings for your existing profile.

Wireless Network Properties:

Profile Name: lanready-wireless

Network Name (SSID): lanready-wireless

This is a computer-to-computer (ad hoc) network; wireless access points are not used.

Channel: 9 (2452MHz)

Wireless network security

This network requires a key for the following:

Network Authentication: WPA-PSK

Data encryption: AES

ASCII PASSPHRASE

Key index (advanced): 1

Network key: *****

Confirm network key: *****

802.1x configure

EAP TYPE : GTC

Tunnel :

Username :

Identity :

Password :


Certificate :

OK Cancel

Once you are finished entering the settings, click **OK** to save the changes.

4.3 Available Network

The **Available Network** tab displays all the available wireless networks detected by the Wireless Adapter.




Simply select the wireless network you wish to connect to and double click. If you have created multiple profiles, you can choice the SSID. Then click **Add to profile** to enable that profile.



4.4 Configuring Encryption

This section describes the different types of encryption available and how to configure them. In most cases, encryption will be automatically configured and all that will need to be entered is the key, as described in **Section 3 Step 2**. The only time you will need to manually configure the encryption settings is if you are creating a custom profile.

Click on **Profile** then **Add**.

The profile settings box will appear. This is where you will change your encryption settings. As you can see you have some different options to choose from.





These three are meant for the home user:

Disable: No encryption in use

WEP: The most popular but least secure form of encryption

WPA/WPA2-PSK: The most secure and recommended level of encryption

The remaining two are for use in a corporate environment that utilizes authentication servers. If you do not know if you have an authentication server, you probably don't and will want to stick with the three options above.

Configuring WEP encryption

The screenshot shows the 'Wireless Network Properties' dialog box. The 'Profile Name' and 'Network Name (SSID)' are both set to 'lanready-wireless'. The 'Channel' is set to '9 (2452MHz)'. Under 'Wireless network security', the 'Data encryption' is set to 'WEP'. The 'Network Authentication' is set to 'Shared Key'. The 'ASCII' and 'PASSPHRASE' checkboxes are unchecked. The 'Key index (advanced)' is set to '1'. The 'Network key' and 'Confirm network key' fields are empty. The '802.1x configure' section is visible on the right, with 'EAP TYPE' set to 'GTC'.

Select **WEP** from the **Data encryption** box.

Under **Network Authentication**, you will want to select **Shared key** or **Open System**, depending on the router settings.

ASCII / PASSPHRASE will also be predetermined by the router. Refer to your routers settings to find out what you should select here.

Key Index is the key on the router that is currently in use. Refer to your routers settings to find out what you should choose.

Once you are done, click **OK** to save your settings.

Configuring WPA/WPA2-PSK Encryption (for home users)

The screenshot shows the 'Wireless Network Properties' dialog box. The 'Network Authentication' dropdown is set to 'WPA-PSK' and the 'Data encryption' dropdown is set to 'TKIP'. The 'Network key' and 'Confirm network key' fields are empty. The '802.1x configure' section is visible on the right.

Select **WPA-PSK/WPA2-PSK** from the **Network Authentication** box.

Under **Data encryption** select either **TKIP** or **AES** depending on the settings for your router.


Enter the encryption key into the **KEY** box.

Configuring WPA/WPA2 Encryption (for corporate networks)

The screenshot shows the 'Wireless Network Properties' dialog box. The 'Wireless network security' section is expanded, showing 'This network requires a key for the following:'. The 'Network Authentication' dropdown is set to 'WPA 802.1X' and the 'Data encryption' dropdown is set to 'AES'. The '802.1x configure' section is also visible, with 'EAP TYPE' set to 'GTC'. The 'Network key' and 'Confirm network key' fields are empty. The 'OK' and 'Cancel' buttons are at the bottom.

Select **WPA 802.1x / WPA2 802.1x** from the **Network Authentication** box.

Under **Data encryption** select either **TKIP** or **AES** depending on the settings for your router.




The adapter supports GTC, TLS, LEAP, TTLS, and PEAP authentication methods. Refer to your system administrator for information about what settings you should enter here.

4.5 Ad-hoc and Peer-to-Peer Wireless Networks

Ad-hoc networking is used when you want to connect two or more computers together but you don't have a router.

In ad-hoc mode, you lose a lot of the features that come with a router. The maximum connection speed drops significantly to 11Mbps. WEP encryption is the only security available in ad-hoc mode.

To set up ad-hoc mode, you will need to create a new profile.



Open the **Wireless Monitor**.

Click on **Profile**, then click on **Add**. The profile settings box will appear.

The screenshot shows the 'Wireless Network Properties' dialog box. The 'Profile Name' and 'Network Name(SSID)' fields are highlighted with red boxes. The 'Channel' dropdown is set to '1 (2412MHz)'. The 'Wireless network security' section shows 'Network Authentication' set to 'WPA-None' and 'Data encryption' set to 'AES'. The '802.1x configure' section has 'EAP TYPE' set to 'GTC'. The 'OK' and 'Cancel' buttons are at the bottom.

First change the network type to **Adhoc**. (Infrastructure is for when you are using a router).

Enter a profile name into the **Profile Name** box so that you can identify the profile.


Type in a network name (SSID) into the **SSID** box

Select your desired **Channel**

You can also choose between no security or WEP security. If you choose WEP security, you can follow the instructions in the **Configuring Encryption** section of the manual.

Click **OK** to save the profile.

Once that is done, click on the **Available Network**.



Select your new profile from the profile chooser and double click to enable the profile.

You will need to configure all other computers that you are planning on connecting to your ad-hoc network with the same settings that you input on this screen. Every computer has to be set up exactly the same. If any of the settings are different, the network will not function.


Troubleshooting: If you are having trouble connecting, if the connection is slow, or if it is unstable, you will want to try changing channels. Start with channel 1 and work your way up until you find a channel that gives you a stable connection. Each time you change the channel, save the settings, then reboot the computer. Also make sure that you do this on every ad-hoc machine so that they will all be set to the same channel.

4.6 Wi-Fi Protected Setup (WPS)


Wi-Fi Protected Setup™ (**WPS**) is a new and easy way to configure the encryption for your wireless network clients. In order to use it with your router, firstly, you will need to have a router that supports this feature, like the AR670W Wireless N Router. Secondly, you must configure the wireless encryption on the router; you can find instructions for configuring it in the User Manual located on the CD that came with your router. If your wireless router does not support WPS, you will need to set up the wireless security manually and you can skip this section.

In the instructions below, we are going to use the utility, Wireless Monitor that comes with the Wireless N adapters and the Wireless router as the example.


Step 1 Go to the computer with the Wireless N adapter and open the Wireless Monitor. Click on the **Wi-Fi Protect Setup** or push hardware push button.



Step 2 Choose your configuration method, either **Push Button** or **Pin Code** and click **Next**.




Step 3a If you choose the Push Button method, make sure that you click on the **Push Button Config** button.




Step 3b Push the WPS button on the router, and the blue LED will start blinking. The router will now start the handshake with the wireless adapter, then the connection will be built up in couple minutes.

Note: You will find the WPS button at the same place on Support WPS Wireless N Router.

Step 4a If you choose the Pin Code method, write down the **PIN** and click **Yes**.



Choice you want to connect AP then click **Select**



Step 4b Log in to your router's configuration page from the web browser and click on **Wireless**. Then click **Wireless security**. Make sure that the Wi-Fi Protected Setup **Enable** box is checked. Click the **Add Wireless Device Wizard** button.

Step 4c Enter the Pin Code in the **Pin Number** box and click **Connect**.

After a few moments both the router configuration screen and the adapter configuration screen should show a message telling you that you are connected.


Step 4d Click **Continue** on the router configuration screen.

Note: If you cannot connect successfully with WPS, you need to log in to your router's configuration and click on **Wireless**. Then click **Wireless security**. Make sure that the Wi-Fi Protected Setup **Enable** box is checked.

4.7 Access Point Mode

Access point mode allows you to set up your computer to act as a wireless router and share its existing wired connection with other computers. In order to use this mode, the computer will need to be hard wired directly to the internet.


To switch into access point mode click on **Mode** at the top of the utility window and click on **Access Point**.



The system tray icon will change:



And the interface will change providing you with new options:




SSID displays the current SSID setting of the adapter. The SSID is what other computers will need to look for when trying to connect to your adapter.

BSSID is the physical address or MAC address of your wireless adapter.

Association Table shows you the remote computers that are currently connected to your wireless adapter.

Clicking **Config** will take you to the following menu:

In the **Advanced** tab, you can change settings like **Beacon Interval**, **DTIM Period**, and **Preamble Mode** to fine tune your adapter's connection. Click apply after making changes so that they take effect. If you need to change the settings back to what they were originally, click on **Set Defaults**, then click **Apply**.




Here you can set all of the options for your adapter.


Network Name(SSID) this is the name that your wireless adapter will be broadcasting.

Channel allows you to select which channel you want the network to operate on. You may want to change this if you are having connectivity issues.

Wireless Network Security can be set if you want to secure your network. The process is the same as client mode and you can follow the instructions in Section 4.4 to configure the encryption.




ICS or Internet Connection Sharing shows the device that the adapter is using to provide an internet connection to wireless clients. This is automatically configured during the setup.



4.8 About

The About tab shows the Utility, Driver versions.



Appendix A – Features

Frequency Band

- 2.4~2.5 GHz

Standards

- IEEE 802.11b / 802.11g
- 802.11n draft 2.0

Interface

- USB 2.0

Security

- WEP, TKIP, AES-CCMP, WPA-PSK, WPA2-PSK, 802.1x, , EAP-TLS, EAP-TTLS, PEAP(EAP-GTC), PEAP(EAP-MSCHAPv2), Jumpstar2.0

Transmitted Power

- 802.11b: 19 dBm
- 802.11g: 16 dBm
- Draft 11n: 16 dBm

Data Rate

- Transmitting: Up to 300Mbps*
- Receiving: Up to 300Mbps*

System Requirements

- 300 MHz processor or better
- 512Byte RAM
- Available USB port

OS Compatibility

- Windows 2000/XP/Vista
- linux
- MAC OS 10.4/10.5

Dimensions

- 33 x 15 x 7mm (L x W x H)

Temperature

- Operating: 0°C to 55°C
- Storage: -20°C to 70°C

Humidity

- Operating: 10% to 80% Non-Condensing
- Storage: 5% to 90% Non-Condensing

Warranty

- Limited 1-year warranty

Safety Approvals

- FCC, CE, IC

Appendix B – Information

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IEEE 802.11b or 802.11g operation of this product in the U.S.A. is firmware-limited to channels 1 through 11.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. To maintain compliance with FCC RF exposure compliance requirements, please follow operation instruction as documented in this manual.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

SAR compliance has been established in typical laptop computer(s) with USB slot, and product could be used in typical laptop computer with USB slot. Other application like handheld PC or similar device has not been verified and may not compliance with related RF exposure rule and such use shall be prohibited.

Industry Canada Statement

This device complies with RSS-210 of the Industry Canada Rules. Operation is subject to the following two conditions:

- 1) this device may not cause interference and
- 2) this device must accept any interference, including interference that may cause undesired operation of the device

IMPORTANT NOTE:

IC Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. To maintain compliance with IC RF exposure compliance requirements, please follow operation instruction as documented in this manual.

Technical Support

E-mail:

TEL : +886 2 27968188

Web Site: www.lanready.com

*Theoretical maximum wireless signal rate derived from IEEE 802.11g standard and IEEE 802.11n draft specification version 2.0. Actual data throughput will vary. Network conditions and environmental factors, including volume of network traffic, building materials and construction, mix of wireless products used, radio frequency interference (e.g., cordless telephones and microwaves) as well as network overhead lower actual data throughput rate. Specifications are subject to change without notice. All products and trademarks are the property of their respective owners. Copyright ©2008 LanReady®