## Wireless-Bridge

In this next screen, you can select which mode you want the router to be in, either access point or wireless bridge. If you enable bridge restrict, then enter the MAC addresses of the remote bridges. If you disable the bridge restrict function, then there are no MAC addresses to enter. Click on **Save / Apply** to save and continue.

Home	Advanced	Tools	Status
Wireless Bridge	9		
This page allows you t select Wireless Bridge functionality. Selecting will still be available ar Bridge Restrict which o access. Selecting Enab bridges selected in Rei Click "Refresh" to upda Click "Save/Apply" to o AP Mode: Bridge Enableo	o configure wireless bridge f (also known as Wireless Dis Acess Point enables access ad wireless stations will be a lisables wireless bridge restr led or Enabled(Scan) enable mote Bridges will be granted ite the remote bridges. Wait onfigure the wireless bridge Point	eatures of the wireless tribution System) to di point functionality. Wir ble to associate to the iction. Any wireless br s wireless bridge restr access. for few seconds to up options.	s LAN interface. You can sables acess point reless bridge functionality AP. Select Disabled in idge will be granted riction. Only those date.
Restrict:			
Remote Bridges MA	C'Address:		
	Refresh Sav	e/Apply	

## Wireless-QoS

WMM (Wi-Fi Multimedia) technology is available on the wireless router, allowing you to give multimedia applications a higher quality of service and priority in a wireless network so applications such as videos will be of higher quality. Enabling WMM may delay the network traffic of other lower assigned quality applications.

WMM No Acknowledgement can be enabled if you enable WMM which refers to the acknowledgement policy used at the MAC level.

To create a QoS entry, click the Add QoS Entry button to proceed to add or remove traffic class rules for your network. Click on Save/Apply WME Settings.

MM(Wi-Fi Multimedia) Settings WMM(Wi-Fi Multimedia): Enabled WMM No Acknowledgement: Disabled Wireless Qos Classes Choose Add or Remove to configure network traffic classes. Class Priority Protocol Source Dest. Dest. Name Priority Protocol Addr./Mask Port Addr./Mask Port	Hom	e	Advanced	Tool	S	Status
WMM(Wi-Fi Multimedia):   Enabled     WMM No Acknowledgement:   Disabled     Wireless Qos Classes   Disabled     Choose Add or Remove to configure network traffic classes.     Class   TRAFFIC CLASSIFICATION RULES     Name   Priority     Protocol   Source     Add QoS Entry   Save/Apply WME Settings	1M(Wi-Fi	i Multim	iedia) Settings			
Wireless Qos Classes     Choose Add or Remove to configure network traffic classes.     TRAFFIC CLASSIFICATION RULES     Priority   Dest.     Priority   Dest.     Priority   Dest.     Add QoS Entry   Save/Apply WME Settings	WMM(Wi-F WMM No 7	=i Multime Acknowled	edia): Igement:	Enabled • Disabled •		
Choose Add or Remove to configure network traffic classes.       Class     TRAFFIC CLASSIFICATION RULES       Name     Priority     Protocol     Source     Dest.     Dest.       Add QoS Entry     Save/Apply WME Settings     Save/Apply WME Settings     Save/Apply WME Settings						
Class Name   TRAFFIC CLASSIFICATION RULES     Priority Name   Protocol   Source Addr./Mask   Source Port   Dest. Addr./Mask   Port     Add QoS Entry   Save/Apply WME Settings   Save/Apply WME Settings   Save/Apply WME Settings	Wireless	Qos Clas	ses			
Name     Priority     Protocol     Source Addr./Mask     Source Port     Dest. Addr./Mask     Dest.       Add QoS Entry     Save/Apply WME Settings     Save/Apply WME Settings     Save/Apply WME Settings     Save/Apply WME Settings	Wireless Choose Ac	<b>Qos Clas</b> Id or Rem	<b>ses</b> ove to configure net	work traffic classes.		
Add QoS Entry Save/Apply WME Settings	Wireless Choose Ac	Qos Clas Id or Rem	ses ove to configure net	work traffic classes.	ON RULES	
Add QoS Entry Save/Apply WME Settings	Wireless Choose Ac Class Name	Qos Clas Id or Rem Priority	ses ove to configure net TF Protocol Sour Addr.M	work traffic classes. AFFIC CLASSIFICATIO ce Source Mask Port	ON RULES Dest. Addr.:Mask	Dest. Port
	Wireless Choose Ac Class Name	Qos Clas Id or Rem Priority	ses ove to configure net TF Protocol Sour Addr.M	work traffic classes. AFFIC CLASSIFICATIO ce Source Task Port	ON RULES Dest. Addr.:Mask	Dest. Port
	Wireless Choose Ac Class Name	Qos Clas Id or Rem Priority Add	ses ove to configure net TF Protocol Sour Addr./N QoS Entry	work traffic classes. AFFIC CLASSIFICATIO ce Source Task Port Save/Apply WME	ON RULES Dest. Addr.:Mask Settings	Dest. Port
	Wireless Choose Ac Class Name	Qos Clas Id or Rem Priority Add	ses ove to configure net TF Protocol Sour Addr.M QoS Entry	work traffic classes. AFFIC CLASSIFICATIO ce Source Task Port Save/Apply WME	ON RULES Dest. Addr.Mask Settings	Dest. Port

# Tools

The tools section contains various administrator functions to maintain your router. Sections include the following—Admin, Time, Remote Log, System, Firmware, and Test.

- Admin: Allows you to change the password for the various user names available
- Time: Allows you to set the router's time
- Remote Log: Allows you to view logs of the router's activities
- System: Allows you to perform functions such as save / reboot, backup, update settings, and restore default settings
- Firmware: Allows you to upgrade your router with new available firmware versions
- Test: Allows you to view test information for your Internet connection

#### **Access Control**

You can enable or disable some services of your router by LAN or WAN. If no WAN connection is defined, only the LAN side can be configured.

D-Link Building Networks for People			DSL-2640	U
	(Home (	Advanced	Tools	Status
Access Control	Access Control Manage DSL Router	Admin user accounts.		
Remote Log TR-059 Client	Access Control A Service Control List	Services t ("SCL") enables or disables	services from being used	1.
System	Access Control	IP Address		
Firmware	Permits access to loc	al management services.	55	
Test Logout				

## Access Control-Admin

Three user names and passwords—admin, support, and user—can be used to control your router. The passwords for these user names can be changed on the following screen. Enter the user name followed by the old password and the new password that you wish to change to.

Home (	Advanced	Tools	Status
Administrator Sett	ings		
Access to your DSL rout	er is controlled through thre	e user accounts: adm	nin, support, and user.
The user name "admin" Router.	has unrestricted access to	change and view conf	iguration of your DSL
The user name "suppor maintenance and to run	t" is used to allow an ISP te diagnostics.	chnician to access you	ur DSL Router for
The user name "user" c well as, update the rout	an access the DSL Router, v er's software.	view configuration set	tings and statistics, as
Use the fields below to a Note: Password cannot	enter up to 16 characters ar contain a space.	nd click "Apply" to cha	nge or create passwords.
Username:	•		
Old Password:			
New Password:			
Confirm Password:			
		2	
	Арј	bly	

## Access Control–Services

Services that can be enabled / disabled on the LAN / WAN are FTP, HTTP, ICMP, SNMP, Telnet, and TFTP.

Home	/ Advar	iced 🦲	Tools	Status
ccess Contro	I Services			
Service Control Li	st ("SCL") enables	or disables se	rvices from bei	ng used.
	Service	LAN	WAN	
	FTP	Enabled	Enabled	
	НТТР	🔽 Enabled	Enabled	
	ICMP	🔽 Enabled	🗆 Enabled	
	SNMP	🗹 Enabled	🗆 Enabled	
	TELNET	Enabled	🗆 Enabled	
	TETP	🗹 Enabled	🗆 Enabled	
		<b>O</b> Apply		

## Access Control-IP Address

Web access to the router can be limited when Access Control Mode is enabled. The IP addresses of allowed hosts can be added using Access Control $\rightarrow$ IP Address.

Add the IP address to the IP address list by clicking on the **Add** button, then select "**Enabled**" to enable Access Control Mode.



To assign the IP address of the management station that is permitted to access the local management services, enter the IP address in the box and click on the **Apply** button.

Home	Advanced	Tools	Status
IP Address			
Enter the IP address services, and click 'Ap	of the management station pply.'	n permitted to access the	local management
IP Address:		]	
		0	
		Apply	

## Time

The Time Settings page allows you to automatically synchronize your time with a time server on the Internet.



If you choose to set the router's time, click on the "automatically synchronize with Internet time servers" checkbox and the below fields appear.

Home 🌔	Advanced 🧧	Tools	Status
Time settings			
This page allows you to the n	nodem's time configur	ation.	
Automatically synchronize	e with Internet time se	ervers	
First NTP time server:	Clock.tmt.ne.net		
Second NTP time server:	None		
Time zone (GMT-12:00 offset:	)) International Date L	ine West	•

Select from the list of NTP (Network Time Protocol) time servers. Then select the time zone that you are in and click on **Apply** to save.

#### Remote Log

The Log dialog allows you to view and configure the log. To view the log, click on the **View System Log** button.

Home	Advanced	Tools	Status
System Log Int	го		
The System Log dialog	g allows you to view the Syst	em Log and configure t	he System Log options.
Click "View System Lo	g" to view the System Log.		
Click "Configure System	m Log" to configure the Syste	em Log options.	
	View System Log	Configure System Log	

Below is the **System Log** screen which shows the date/time of the log, the facility that was logged, the severity level and the log message. Click on **Refresh** to view any new information that is logged.

System Log when log mode is DISABLED	Home System Log Date/Time Facility	Advanced Severity Message	Tools	Status	NOTE: When you click on the View System Log button, the System Log screen that you access will be located under the Status section (see screen on left). To return to the previous screen to configure system log, remember to click on the Tools tab (located on top row) first and then click on Remotelog.
System Log when log mode is ENABLED	Home System Log Date/Time F Gate Contact of Dan 1 00:80:22 (	Advanced (	Tools Message Hed. Busystok (d. cf) (2) ak UP.	<b>Status</b>	

To configure the system log settings, click on the **Configure System Log** button to view the following screen.

( Home	Advanced	Tools	Status
System Log (	Configuration		
If the log mode is er all events above or events above or equ 'Both,' events will bo the selected mode i	nabled, the system will be equal to the selected level ual to the selected level wi e sent to the specified IP a is 'Local' or 'Both,' events v	gin to log all the selected will be logged. For the Di Il be displayed. If the sele ddress and UDP port of th vill be recorded in the loca	events. For the Log Level, splay Level, all logged cted mode is 'Remote' or ie remote syslog server. If al memory.
Select the desired v	values and click 'Apply' to c	onfigure the system log o	ptions.
Log:	Disable O Enable		
Log Level:	Debugging 💌		
Display Level:	Error		
Mode:	Local 💌		
	,	<b>O</b> Apply	

If the log is enabled, the system will log selected events including *Emergency*, *Alert*, *Critical*, *Error*, *Warning*, *Notice*, *Informational*, and *Debugging*. All events above or equal to the selected log level will be logged and displayed.

If the selected mode is "Remote" or "Both", events will be sent to the specified IP address and UDP port of a remote system log server. If the selected mode is "Local" or "Both", events will be recorded in the local memory. Select the desired values and click on **Apply** to configure the system log options.

#### **TR-069** Client

The router includes a TR-069 client, a WAN management protocol. All the values are already filled in. If you wish to enable this protocol, then select *enable*. You must click on the **Apply** button for the setting to take place.

f Home f	Advanced 📔	Tools	Status
TR-069 client - Confi	iguration		
WAN Management Protocol configuration, provision, coll	(TR-069) allows a Auto-( ection, and diagnostics to	Configuration Server (A ) this device.	CS) to perform auto-
Select the desired values an	nd click "Apply" to configu	re the TR-069 client op	otions.
Inform © Disa	able C Enable		
Inform Interval:	300		
ACS URL:			
ACS User Name:	admin		
ACS Password:	****		
Connection Request (	Jser Name: admin		
Connection Request F	Password: ****		
	🥑 🔄		
	Apply G	etRPCMethods	

#### System

The system section includes several tools on one page, including save and reboot, backup settings, update settings, and restore default settings.

#### Save and Reboot

To save all configurations made, click on the **Save/Reboot** button. This will save all your settings and restart the router for the settings to take effect.



When completed, the below pop-up window will appear confirmation that the router has been rebooted.



#### **Backup Settings**

To save your configurations in a file on your computer so that it may be accessed again later if your current settings are changed, click on the **Backup Settings** button. The below pop-up screen will appear with a prompt to open or save the file to your computer.

File Dowr	nload 🔀
?	Some files can harm your computer. If the file information below looks suspicious, or you do not fully trust the source, do not open or save this file.
	File name: backupsettings.conf
	File type:
	From: 192.168.1.1
	Would you like to open the file or save it to your computer?
	Open Save Cancel More Info
	✓ Always ask before opening this type of file

## **Update Settings**

To load a previously saved configuration file onto your router, click **Browse** and select the file on your computer and then click on **Update Settings**.

(Home (	Advanced	Tools	Status
System - Update S	ettings		
Update DSL router se	attings. You may update	your router settings using yo	ur saved files.
Settings File Name:	Br	owse	
	Update S	ettings	

The router will restore settings and reboot to activate the restored settings.

## **Restore Default Settings**

Restore Default will delete all current settings and restore the router to factory default settings. Click on the **Restore Default Settings** button to proceed. The

following confirmation dialog will appear confirming your decision to restore default settings. Click on **OK** to continue.



Click on the **OK** button to start. The below screen will appear with the progress of restoring the default settings.



When completed, the below pop-up window will appear confirmation that the router has been rebooted.



#### Firmware

If your ISP releases new software for this router, follow these steps to perform an upgrade.

- 1. Obtain an updated software image file from your ISP.
- 2. Enter the path to the image file location or click on the **Browse** button to locate the image file.
- 3. Click the Update Software button once to upload the new image file.

ſ	Home	1	Advanced	Tools	Status
Fir	mware Upgr	ade			
	Step 1: Obtain a	an update	ed software image file	e from your ISP.	
	<b>Step 2:</b> Enter th to locate the ima	ie path to ige file.	) the image file locatio	in the box below or cli	ick the "Browse" button
	Step 3: Click the	e "Update	e Software" button on	ce to upload the new im	age file.
	NOTE: The upda reboot.	te proces	ss takes about 2 minu	tes to complete, and you	ır DSL Router will
	Software File N	Jame:		Browse	
			Update	Software	

The below page will appear when you click on the **Update Software** button.

🚰 D-Link ADSL Router - Microsoft Internet Explorer	
File Edit View Favorites Tools Help	
📙 🖙 Back 🔹 🤿 🖉 🙆 🚰 🛛 🐼 Search 🕋 Favorites 🛞 Media 🚳 🔂 🔹 🎽	D - 🗵
Address 🙆 http://192.168.1.1/index.html	<i>∂</i> Go
<b>DSL Router Update</b> Uploading is in progress. The DSL Router will reboot upon completion. Please wait	
Progress: 15%	

When completed, the below pop-up window will appear confirmation that the router has been rebooted.

Microsoft	Internet Explorer	x
₹	DSL Router has been rebooted and is up running	now
	ОК	

#### Test

The diagnostics screen allows you to run diagnostic tests to check your DSL connection. The results will show test results of three connections—

- Connection to your local network
- Connection to your DSL service provider
- Connection to your Internet service provider

There are three buttons at the bottom of the page-Next Connection (appears only if you have created more than one connection), Test and Test with OAM F4-which will allow you to retest if necessary.

(Hom	e (	Advanced	(	Tools		Stat	us
pppoa_0_3	5_1 Diag	nostics					
Your modem is displays a fail st status is consist procedures.	capable of f atus, click "F ent. If the f	esting your DSL conne erun Diagnostic Tests' est continues to fail, c	ection. The ' at the bo :lick "Help"	individual ttom of th and follov	l tests are his page to v the trou	listed belov o make sure bleshooting	w. If a test e the fail J
Test the conn	ection to y	our local network					
Test your	ENET Conn	ection:	PASS	<u>Help</u>			
Test your	Wireless C	onnection:	PASS	<u>Help</u>			
Test the	connection	to your DSL service	provider				
Test ADS	L Synchron	ization:	FAIL	Help			
Test ATM	OAM F5 se	gment ping:	FAIL	Help			
Test ATM	OAM F5 en	d-to-end ping:	FAIL	<u>Help</u>			
Test the	connection	to your Internet se	rvice prov	vider			
Test PPP	server ses	sion:	FAIL	Help			
Test auth	entication v	vith ISP:	N/A	Help			
Test the a	assigned IP	address:	FAIL	Help			
Ping defa	ult gateway	:	FAIL	Help			
Ping prim	ary Domain	Name Server:	FAIL	Help			
		Test	t With OAM	IF4			

## Status

The status section allows you to view general and status information for your router's connection.

## **Device Info**

It shows details of the router such as the version of the software, bootloader, LAN IP address, etc. It also displays the current status of your DSL connection as shown below—

le		DSL-2640U	J
Home A	dvanced (	Tools	Status
Device Info			
Board ID:	D-4D-)A/		1
Software Version:	BU DSI -2640U 3-0	6-04-1000.A2pB021c.d19h	
Bootloader (CFE) Version:	1.0.37-6.5		
Wireless Driver Version:	3.131.35.0.cpe2.3		
Line Rate - Upstream (Kbr Line Rate - Downstream (I	os): (bps):		
Line Rate - Upstream (Kbr	is):		
Line Rate - Downstream (I	(bps):		
LAN IP Address:	192,168,1,1		
Default Gateway:			
Primary DNS Server:	192,168,1,1		
Secondary DNS Server:	192,168,1,1		

## **DHCP** Clients

Access the DHCP Leases screen by clicking "DHCP" under "Statistics". This shows the computers, identified by the hostname and MAC address that have acquired IP addresses by the DHCP server with the time that the lease for the IP address is up.

Home	Advanced	Tools	Status
Device Info DH	CP Leases		
Hostname MAC A	Address   IP Address   Expi	res in	

## WAN Info

The WAN Info screen displays WAN connections previously set up in the Home section. The information added in the status section is the extra column for connection status information, displaying either ADSL Link Down or ADSL Link Up.

VPI/VCI	Category	Service Name	Interface Name	Protocol	State	Status	IP Address
0/35	UBR	pppoa_0_35_1	ppp_0_35_1	PPPoA	Enabled	ADSL Link Down	
2/38	UBR	pppoe_2_38_1	ppp_2_38_1	PPPoE	Enabled	ADSL Link Down	

## **Route Info**

The Route Info section displays route information showing the IP addresses of the destination, gateway, and subnet mask as well as other route information.

s:U-un.L-	reject. G -	dateway, H - I	host. R	- reinsta	ate		
lynamic (red	irect), M -	modified (redir	rect).	101100			
Destination	Gateway	Subnet Mask	Flags	Metric	Service	Interface	
192,168,1,0	0.0.0.0	255,255,255,0	U	0		br0	

## Log

This is the same screen as seen in the Remotelog section under tools.

Home	1	Adva	anced (	Тоо	ls 🛛	Status	
System Log							
		-					
Date/Time	Facility	Severity	86M96345 cts	Mes rted: BusyBoy :	isage v1 oo (2005	104.12	
00:12:36	syslog	emerg	18:11+0000)			50 T. 12	
Jan 1 00:12:36	user	crit	kemel: eth0 L	ink UP.			
				-			
			Refre	sh			

## LAN

The LAN section shows received and transmitted packet information for the Ethernet interfaces. Click on **Reset Statistics** to renew the information.

## WAN

The WAN section shows received and transmitted packet information for the WAN connections that you have set up. Click on **Reset Statistics** to renew the information.

Service	VPI/VCI	Protocol	Interface		Rec	eived			Trans	smitte	1.
				Bytes	Pkts	Errs	Drops	Bytes	Pkts	Errs	Drops
oppoa_0 _35_1	0/35	PPPoA	ppp_0_3 5_1	0	0	0	0	0	0	0	0
oppoe_2 38 1	2/38	PPPoE	ppp_2_3 8 1	0	0	0	0	0	0	0	0

## ATM

The ATM section displays statistical values for your ATM interface as well as for AAL5 and AAL5 VCC. Click on **Reset Statistics** to renew the values.

itistics ATM			TOOIS	Status
usues Ann				
Interface Statistics				
In Octets		2451	1	
Out Octets		1412	1	
In Errors		0		
In Unknown		0	-	
In Hec Errors		0		
In Invalid Vpi Vci Errors		0		
In Port Not Enable Erro	rs	0		
In PTI Errors		0		
In Idle Cells		0		
In Circuit Type Errors		0		
		0		
In OAM RM CRC Errors				
In OAM RM CRC Errors In GFC Errors 5 Interface Statistics		0		
In OAM RM CRC Errors In GFC Errors 5 Interface Statistics In Octets		5195	]	
In OAM RM CRC Errors In GFC Errors 5 Interface Statistics In Octets Out Octets		5195 1762	]	
In OAM RM CRC Errors In GFC Errors 5 Interface Statistics In Octets Out Octets In Ucast Pkts		5195 1762 69		
In OAM RM CRC Errors In GFC Errors 5 Interface Statistics 5 In Octets Out Octets In Ucast Pkts Out Ucast Pkts		5195 1762 69 19		
In OAM RM CRC Errors In GFC Errors 5 Interface Statistics 0 Octets Out Octets In Ucast Pkts Out Ucast Pkts In Errors		5195 1762 69 19 0		
In OAM RM CRC Errors In GFC Errors 5 Interface Statistics Out Octets In Ucast Pkts Out Ucast Pkts In Errors Out Errors		5195 1762 69 19 0 0		
In OAM RM CRC Errors In GFC Errors 5 Interface Statistics Out Octets In Ucast Pkts Out Ucast Pkts In Errors Out Errors In Discards		5195 1762 69 19 0 0 0		

## ADSL

Information contained in the ADSL screen is useful for troubleshooting and diagnostics of connection problems.

Home	Advanced		Tools	Status
SL Statistics				
Mode:			G.DMT	
Type:			Fast	
Line Coding:			Trellis On	
Status:			No Defect	
Link Power State:			LO	
		Downstre	eam Upstream	
SNR Margin (dB):		11.9	12.0	
Attenuation (dB):		0.0	1.0	
Output Power (dBr	n):	7.8	12.5	
Attainable Rate (Kl	ops):	9568	1056	
Rate (Kbps):		8000	800	
K (number of bytes	s in DMT frame):	251	26	
R (number of chec	k bytes in RS code word):	0	D	
S (RS code word s	ize in DMT frame):	1	1	
D (interleaver dept	h):	1	1	
Delay (msec):		D	þ	
Super Frames:		18171	18169	
Super Frame Error	'S:	1	200	
RS Words:		0	0	
RS Correctable Err	rors:	o	O	
RS Uncorrectable	Errors:	0	N/A	
HEC Errors:		1	86	
OCD Errors:		0	0	
LCD Errors:		0	D	
Total Cells:		5829071	D	
Data Cells:		1040	D	
Bit Errors:		o	D	
Total ES:		2	D	
Total ES: Total SES:		2 1	0 D	

ADSL BER Test

Reset Statistics

#### **ADSL BER Test**

A **Bit Error Rate Test (BER Test)** is a test that reflects the ratio of error bits to the total number transmitted.

If you click on the **ADSL BER Test** button at the bottom of the ADSL Statistics page, the following pop-up screen will appear allowing you to set the tested time and to begin the test.



When you start the ADSL BER Test, the following progress window will display the connection speed as well as the length of time that the test will run for. At any time during the test, click on the **Stop** button to terminate the test.



When the test is complete, the following window will display the test results showing the test time, total transferred bits, total error bits and error ratio.

he ADSL BER test comp	bleted successfully.
Test Time (sec):	20
Total Transferred Bits:	0x00000008A31680
Total Error Bits:	0x0000000000000000
Error Ratio:	0.00e+00

## Wireless Station Info

This page displays the stations (identified by their BSSID) that are associated with your wireless router. Click on **Refresh** to renew the page for new wireless stations.

Home (	Advar	nced (	Tools	Status
eless Authent	icated Sta	tions		
age shows authent	icated wirele	ss stations and	their status	
BSSID	Associated	Authorized		
00:15:00:4C:58:4E				
00:15:00:4C:58:4E	Associated	Autorized		
		Refresh	í -	