

Home Security Camera OC825

User Guide

Table of Contents

CHAPTER 1 INTRODUCTION	1
Package Contents	1
Features	1
LEDs	2
CHAPTER 2 INITIAL INSTALLATION	4
Requirements	4
Procedure	4
CHAPTER 3 SPECIFICATIONS	6
Specifications	6
Customized RJ45 & Power Supply	6
Day/Night Mode.....	7
Regulatory Approvals	8

Copyright © 2011. All Rights Reserved.

Document Version: 1.0

All trademarks and trade names are the properties of their respective owners.

Chapter 1



Introduction

This Chapter provides an overview of the iCamera's features and capabilities.

Congratulations on the purchase of your new iCamera. The iCamera is a Day and Night Network Camera with VGA resolution and 802.11n WiFi connectivity.

Package Contents

The following items should be included:

- The iCamera Unit
- Bracket * 1
- Y-Cable * 1 with boot
- Adapter * 1

If any of the above items are damaged or missing, please contact your dealer immediately.

Features

- DDR2 128MB with 16MB Flash
- One Ethernet port with RJ45 connector
- Dual Omni Vision OV7740 1/5" CMOS Sensor
- Front Panel LEDs
- Reset/ WPS button
- Built-in Microphone
- Daylight Sensor
- Internal antenna for WiFi

LEDs

Front-mounted LEDs

The iCamera has 3 LEDs.



POWER/WiFi (Green)	<ul style="list-style-type: none">• On (Green)- Power On• Off - Power Off• Blinking - Data is being transmitted or received.• Blinking Low - Weak strength of WiFi signal (1/2 Hz, SNR < 15 dB)• Blinking Medium - Strength of WiFi signal is normal (1/2 Hz, SNR < 15 dB)• Blinking High - Good strength of WiFi signal (1/2 Hz, SNR < 15 dB)
Network (Green)	<ul style="list-style-type: none">• On (Green)- LAN/Wireless connection established.• Off - No active connection on the corresponding LAN port, or not associated to Wireless AP• Flashing - Data is being transmitted or received.
WPS (Green)	<ul style="list-style-type: none">• On - When the WPS function is failed, the WPS LED will be lit on for 5 seconds.• Off - WPS function is off.• Flashing - WPS function is being processed. If it is successful, the WPS LED will be off.

Rear Panel



LAN Port	Use standard LAN cable (RJ45 connectors) to connect your PC to the port. PoE (Power over Ethernet) function is supported.
Reset	<p>This button has two (2) functions:</p> <ul style="list-style-type: none">• Reboot. When pressed and released, the iCamera will reboot (restart).• Clear All Data. This button can also be used to clear ALL data and restore ALL settings to the factory default values. <p>To Clear All Data and restore the factory default values:</p> <ol style="list-style-type: none">1. Power On.2. Keep holding the Reset Button down for 8 seconds. <p>Release the Reset Button. The iCamera is now using the factory default values.</p>
Microphone	The built-in microphone is useful for bi-direction voice conversation.

Chapter 2

2

Initial Installation

This Chapter covers the software installation of the iCamera.

Requirements

- Network cable. Use standard 10/100BaseT network (UTP) cable with RJ45 connector.

Procedure

1. Choose an Installation Site

Select a suitable place to install the iCamera.

2. Disassemble the Mount kit

Disassemble the mount kit in order to connect the LAN cable.

1. Take out the wall-mount kit from package box.
2. Remove Knob.
3. Use a screwdriver to loosen the screw in order to remove the top cover.



3. Connect LAN Cable

1. Connect LAN cable through the hole.
2. Lock the front cover into wall-mount kit.
3. Put the Knob back.
4. Use LAN cable to connect the device to the Ethernet port on the iCamera.
Note! For the first installation, the user needs to ask the professional's assistance to connect the iCamera and iHub-3001B via the Y-cable (with Ethernet). After the 1st installation is completed, the user will use the Y-cable (without Ethernet) only.



4. Power Up

Connect the supplied power adapter to the iCamera. Use only the power adapter provided. Using a different one may cause hardware damage.

5. Check the LEDs

- The *POWER* LED should be ON.
- The *Network* LED should be ON (provided the PC is also ON.)

Chapter 3

3

Specifications

This Chapter provides specifications for the iCamera.

Specifications

Model	iCamera
Dimensions	72mm (W) x 72mm (H) x 20mm (D) (without bracket)
Operating Temperature	Outdoor: -20° C to 45° C Indoor: 0° C to 45° C
Video compression	H.264, MPEG4 and MJPEG
Network Interface	1 Ethernet 10/100BaseT (RJ45)
Storage Temperature	-20° C to 60° C
LEDs	3
Power Adapter	12V/1A


Customized RJ45 & Power Supply



RJ45 pin definition

pin 1-> TXD+
pin 2-> TXD
pin3-> RXD+
pin 4-> GND
pin 5-> GND
pin 6-> RXD
pin7-> 12V
pin 8-> 12V

Day/Night Mode



Night mode

SerComm P/N# 61930010LA

Vendor P/N# 9347A3B,

Day mode

SerComm P/N# 61930020LA

Vendor P/N# 9347A1B

Regulatory Approvals

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

CE Approval

CE Marking Warning

This is a Class B product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.