

WiFi Combo Broadband Gateway

User Guide

Copyright

The contents of this publication may not be reproduced in any part or as a whole, stored, transcribed in an information retrieval system, translated into any language, or transmitted in any form or by any means, mechanical, magnetic, electronic, optical, photocopying, manual, or otherwise, without the prior written permission.

Trademarks

All products, company, brand names are trademarks or registered trademarks of their respective companies. They are used for identification purpose only. Specifications are subject to be changed without prior notice.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against radio interference in a commercial environment. This equipment can generate, use and radiate radio frequency energy and, if not installed and used in accordance with the instructions in this manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause interference, in which case the user, at his own expense, will be required to take whatever measures are necessary to correct the interference.

CE Declaration of Conformity

This equipment complies with the requirements related to electromagnetic compatibility, EN 55022/A1 Class B.

The specification is subject to change without notice.

Table of Contents

FCC Interference Statement	2
1. Introduction	4
1.1. Package Contents	4
1.2. System Requirements for Configuration	4
1.3. Interfaces - the Rear View	5
1.4. LEDs and Buttons – the Front View	5
1.5. Features	6
2. Configuring WiFi Combo Broadband Gateway	7
2.1. Installation Considerations	7
2.1.1. Installation Instructions- Get Start Networking	7
2.1.2. Establish WiFi Connection	9
3. Using the Configuration Menu	10
3.1. Wizard setting	12
3.2. Administrator’s Main Menu	18
4. Troubleshooting	55
5. Technical Specifications	58

1. Introduction

The WiFi Combo Broadband Gateway is a high-performance tool that supports wireless networking at home, work, or in a public place. The WiFi Combo Broadband Gateway supports a USB 3G modem card, either WCDMA or EVDO and even HSDPA as well, and supports wireless data transfers up to 150M bps, and wired data transfers up to 100 Mbps. The WiFi Combo Broadband Gateway is compatible with industry security features.

1.1. Package Contents

Importance: Check your product package contents FIRST.

The WiFi Combo Broadband Gateway package should contain the items listed below. If any of the items are missing, please contact your reseller.


items	Description	Quantity
1	WiFi Combo Broadband Gateway	1
2	RJ-45 Cable	1
3	Power adapter 5V 2.0A	1
4	CD	1

Caution: Using a power supply with a different voltage rating than the one included with the WiFi Combo Broadband Gateway will cause damage and void the warranty for this product.


1.2. System Requirements for Configuration

- A compatible USB 3G modem card *with service*
- Note:** Subject to services and service terms available from your carrier.
- Computers with Windows, Macintosh, or Linux-based operating systems with an installed Ethernet adapter.
 - Internet Explorer version 6.0 or Netscape Navigator version 7.0 and above.
 - Wi-Fi System Requirements: An 802.11b, 802.11g, or 802.11n Adapter.

1.3. Interfaces - the Rear View



1.4. LEDs and Buttons – the Front View



Note:

Contains a reset button to restore the setting back to original factory defaulted setting as if your convenience of forgetting your applicable setting

1.5. Features

- IEEE 802.11b/g compliant and 11n Lite (HW 1T1R not MIMO solution.)
 - Backward compatible to IEEE 802.11b standards
 - Max physical rate up to 54Mbps in 802.11g mode
 - Max physical rate up to 150Mbps in 802.11n mode
 - Security Supports: WEP (64/128 bits), WPA, WPA2, WPA-PSK, WPA2-PSK, and 802.1x
 - WPS Support
- Provide 5 * 10/100 RJ-45 ports
 - 4 * LAN
 - 1 * WAN
- WAN connection through external USB 3G/3.75G modem card
 - WCDMA,HSDPA,HSUPA(depend on region)
 - CDMA2000,EV-DO(depend on region)
 - TD-SCDMA,TD-HSDPA([Option](#))
 - Flash OFDM([Reserve](#))
 - iBurst([Option](#))
- Built-in NAT function: one IP sharing with PCs
- Built-in firewall to protect your Intranet
- VPN pass through supported
 - PPTP
 - L2TP
 - IPSec
- Easy to upgrade firmware
 - Web UI
 - Windows utility
- Easy to manage:
 - Web UI
 - SNMP
 - UPnP
- Network Protocols
 - UDP/TCP/IP/ARP/RARP/ICMP
 - DHCP/PPPoE
 - DNS/TFTP/HTTP
- Antenna
 - 1 x PiFa Wi-Fi antenna

Note: The WiFi Combo Broadband Gateway is designed to work with 3G USB dongle, (either EVDO or WCDMA (UMTS)).

Please refer to your service provider for detailed feature information.

2. Configuring WiFi Combo Broadband Gateway

2.1. Installation Considerations

The WiFi Combo Broadband Gateway allows you access your network using a wireless connection, from virtually anywhere within its operating range. Keep in mind however, that the number, thickness, and location of walls, ceilings, or other objects that the wireless signals must pass through, may limit this range. Typical ranges vary depending on the types of materials used, and background RF (radio frequency) noise in your home or business.

註解 [01]: 加上 to allow you to

註解 [02]: 應改為 However, keep in mind that

To maximize your wireless range, please follow these guidelines:

1. Keep the number of walls and ceilings between the WiFi Combo Broadband Gateway and other network devices to a minimum. Each wall or ceiling can reduce the WiFi Combo Broadband Gateway's range from 3-90 feet (1-30 meters).

Note: The same considerations apply to your broadband EVDO connection.

2. Keep your product aware from electrical devices (such as microwaves, air conditioners, and televisions) that emit large quantities of RFI (Radio Frequency Interference).


註解 [03]: 應改為 away

2.1.1. Installation Instructions- Get Start Networking

Connect this Gateway to Your Network

Note: *DO NOT* connect WiFi Combo Broadband Gateway to power before performing the installation steps below.


1. Connect a USB modem with service to the WiFi Combo Broadband Gateway-- See Picture 2.1



Picture 2.1

Note: The WiFi Combo Broadband Gateway is designed to work with either UMTS or EV-DO and even HSDPA 3G cards that can be used as a modem (support tethered data). Please refer to your service provider for detailed feature information.


2. Insert the Ethernet patch cable into LAN Port on the back panel of the WiFi Combo Broadband Gateway, and an available Ethernet port on the network adapter in the computer you will use to configure the unit.-See **Picture 2.2**



Picture 2.2

Note: The WiFi Combo Broadband Gateway LAN Port is “Auto-MDI/MDIX.” This provides patch Ethernet cable LAN Port access.

3. Connect the power adapter to the receptor on the back panel of your WiFi Combo Broadband Gateway. Then plug the other end of the power adapter into a wall outlet or power strip. –See **Picture 2.3**



Picture 2.3

4. The LEDs

Reference the Section 1.4, LEDs and Buttons– the Front View.



2.1.2. Establish WiFi Connection

If you selected either **WEP** or **WPA-PSK** encryption, ensure these settings match your WiFi adapter settings.

WiFi and encryption settings must match **for** access to the WiFi Combo Broadband Gateway Configuration Menu, and the Internet. Please refer to your WiFi adapter documentation for additional information.

註解 [04]: 删除 for

3. Using the Configuration Menu

Once properly configured, the WiFi Combo Broadband Gateway will obtain and assign IP address information automatically. Configuration settings can be established through the WiFi Combo Broadband Gateway Configuration Menu. You can access this interface by performing the steps listed below:

1. Open a web-browser.
2. Type in the IP Address (<http://192.168.123.254>) of the WiFi Combo Broadband Gateway.



Note: If you have changed the **default** IP Address assigned to the WiFi Combo Broadband Gateway, ensure you enter the correct IP Address now.

3. Type "admin" in the Password field.

WiFi Combo Broadband Gateway (R0.02)

USER's MAIN MENU Status

System Password (default: admin)

System Status [HELP]

Item	WAN Status	Sidenote
IP Address	0.0.0.0	3G
Subnet Mask	0.0.0.0	
Gateway	0.0.0.0	
Domain Name Server	0.0.0.0, 0.0.0.0	
Connection Time	-	

Wireless Modem Information

Item	Status	Sidenote
Card Info	N/A	
Link Status	Connecting...	No Modem Detected
Signal Strength	N/A	
Bytes Transmitted	0	
Bytes Received	0	
Network Name	N/A	

Wireless Status

Item	WLAN Status	Sidenote
Wireless mode	Enable	(B/G/N Mixed)
SSID	default	
Channel	11	
Security	Open	(None)

Statistics Information


Statistics of WAN	Inbound	Outbound
Octets	0	0
Unicast packets	0	0
Multicast packets	0	0

Device Time: Sat, 01 Jan 2000 00:16:37 +0000

4. Click "logon" button.

3.1. Wizard setting

- Press “**Wizard**” button → for basic settings with simpler way. (Please check section 3.1)
- Or you may click on “**Advanced Setup**” → for advanced settings. (Please check the section Administrator’s Main Menu. each item from section 3.2)



- Click on “**Enter**” button to get start.

With wizard setting steps, you could configure the gateway in a very simple way. This configuration wizard includes settings of

- a. **Login Password,**
- b. **Time zone**
- c. **WAN Setup**
- d. **Wireless Setup,**

Press “Next” button to start configuration.

The screenshot shows the 'Setup Wizard' window of the 'WiFi Combo Broadband Gateway (R0.02)'. The window title is 'Setup Wizard' with an '[EXIT]' button in the top right. The main content area contains the text: 'Setup Wizard will guide you through a basic configuration procedure step by step.' Below this, there is a list of six steps, each with a right-pointing arrow: 'Step 1. Setup Login Password.', 'Step 2. Setup Time Zone.', 'Step 3. WAN Setup.', 'Step 4. Wireless Setup.', 'Step 5. Summary.', and 'Step 6. Finish.'. At the bottom of the window, there is a navigation bar with a '< Back' button on the left, a breadcrumb trail '[Start > Password > Time > WAN > Wireless > Summary > Finish!]' in the center, and a 'Next >' button on the right.

Step 1: Allow you to change the system password.

The screenshot shows the 'Setup Wizard - Setup Login Password' window of the 'WiFi Combo Broadband Gateway (R0.02)'. The window title is 'Setup Wizard - Setup Login Password' with an '[EXIT]' button in the top right. The main content area contains three input fields, each with a right-pointing arrow: 'Old Password', 'New Password', and 'Reconfirm'. At the bottom of the window, there is a navigation bar with a '< Back' button on the left, a breadcrumb trail '[Start > Password > Time > WAN > Wireless > Summary > Finish!]' in the center, and a 'Next >' button on the right.

You can change Password here.

It is recommended that you change the system password into the one you prefer to on the basis of security.

1. Key in your Old Password (if it is the first initiation, the “admin” will be the defaulted one).
2. Enter your New Password
3. Enter your Password again for confirmation; it must be the same as the New Password.
4. Then click on “Next” to get into next installation.

Step 2: Allow you to change the Time Zone.



You can change Time Zone here.

Or you can click the button “Detect Again”, the Time Zone will be changed to same with your PC.

Step 3: Select WAN Types will be used for Internet connection
Step3-1: Auto Detecting & Manually Setting WAN Type

註解 [05]: 删除 will be



1. Reference **Section 2.1 Installation Considerations** to setup the environment
2. We are support the Dynamic & PPPOE WAN Type for Auto Detecting.
Click on “Next” button

註解 [06]: 删除 are

Step3-2: Select WAN Type

WiFi Combo Broadband Gateway (R0.02)

ADMINISTRATOR's MAIN MENU | Status | Wizard | Advanced | Logout

Setup Wizard - Select WAN Type [EXIT]

- ISP assigns you a static IP address. (Static IP Address)
- Obtain an IP address from ISP automatically. (Dynamic IP Address)
- Some ISPs require the use of PPPoE to connect to their services. (PPP over Ethernet)
- Some ISPs require the use of PPTP to connect to their services. (PPTP)
- Some ISPs require the use of L2TP to connect to their services. (L2TP)
- Some ISPs require the use of 3G to connect to their services.

< Back | [Start > Password > Time > WAN > Wireless > Summary > Finish!] | Next >

Pick up one of types you preferred to.
Click on “Next” button

註解 [07]: 加上 the
The types

You can select the Static, Dynamic, PPPOE, PPTP, L2TP and 3G WAN Types. We show you How to setup the 3G WAN Type only.

Reference the **Section 3.2.1.1 Primary Setup** for more information

Step 3-3: Setup the 3G WAN will be used for Internet connection.

WiFi Combo Broadband Gateway (R0.02)

ADMINISTRATOR's MAIN MENU | Status | Wizard | Advanced | Logout

Setup Wizard - 3G [EXIT]

LAN IP Address	192.168.123.254
APN	
PIN Code	
Dialed Number	
Account	
Password	

< Back | [Start > Password > Time > WAN > Wireless > Summary > Finish!] | Next >

1. LAN IP Address: The IP address of the LAN interface. The default IP address is: 192.168.123.254

2. Enter the 3G Modem Card information by your 3G broadband service provider.

Click on “Next” button

Step 4: Configure the wireless settings.

The screenshot shows the 'Setup Wizard - Wireless settings' window. At the top, it says 'WiFi Combo Broadband Gateway (R0.02)'. Below that is a navigation bar with 'ADMINISTRATOR's MAIN MENU', 'Status', 'Wizard', 'Advanced', and 'Logout'. The main content area has a tree view on the left with 'Wireless Module', 'Network ID(SSID)', and 'Channel'. To the right of 'Wireless Module' are radio buttons for 'Enable' (selected) and 'Disable'. To the right of 'Network ID(SSID)' is a text box containing 'default'. To the right of 'Channel' is a dropdown menu showing '11'. At the bottom, there are '< Back' and 'Next >' buttons, and a breadcrumb trail: '[Start > Password > Time > WAN > Wireless > Summary > Finish!]'.

1. Select “Enable” or “Disable”. The default setting is “Enable”.
2. Network ID (SSID) will be defaulted.
3. **Channel**→ Select Wireless Channel matching to your local area for Wireless connection.
4. Click on “Next” to continue.

Step 5: Select the Wireless security method of your wireless configuration.

The screenshot shows the 'Setup Wizard - Wireless settings' window. The 'Authentication' dropdown is set to 'WEP'. Under 'Encryption', there are four radio buttons for 'WEP Key 1', 'WEP Key 2', 'WEP Key 3', and 'WEP Key 4', all of which are selected. To the right of each radio button is a dropdown menu set to 'HEX' and a text box containing '1234567890'. At the bottom, there are '< Back' and 'Next >' buttons, and a breadcrumb trail: '[Start > Password > Time > WAN > Wireless > Summary > Finish!]'.

1. Select “WEP” Security type and enter the WEP key.
2. Click on “Next” to continue.

Step 6: Summary

WiFi Combo Broadband Gateway (R0.02)

ADMINISTRATOR'S MAIN MENU | Status | Wizard | Advanced | Logout

Setup Wizard - Summary [EXIT]

Please confirm the information below

[WAN Setting]	
WAN Type	Dynamic IP Address
Host Name	
WAN's MAC Address	
[Wireless Setting]	
Wireless	Enable
SSID	default
Channel	11
Authentication	Auto
Encryption	WEP

Do you want to proceed the network testing?

< Back [Start > Password > Time > WAN > Wireless > Summary > Finish!] Apply Settings

Click on the “Apply Settings” button

Step 7: System is applying.

WiFi Combo Broadband Gateway (R0.02)

ADMINISTRATOR'S MAIN MENU | Status | Wizard | Advanced | Logout

Setup Wizard - Finish [EXIT]

Configuration is Completed.


Please click "Finish" to restart the device.
Or you can click "Configure Again" to setup the wizard again.

Configure Again [Start > Password > Time > WAN > Wireless > Summary > Finish!] Finish

Click “Finish” button to back the Status Page.

3.2. Administrator's Main Menu

3.2.1 Basic Setting



3.2.1.1 Primary Setup

The screenshot displays the 'Primary Setup' configuration page for a WiFi Combo Broadband Gateway (R0.02). The interface includes a top navigation bar with 'ADMINISTRATOR'S MAIN MENU', 'Status', 'Wizard', 'Advanced', and 'Logout'. Below this is a secondary menu with 'BASIC SETTING', 'FORWARDING RULES', 'SECURITY SETTING', 'ADVANCED SETTING', and 'TOOLBOX'. A left sidebar lists 'Primary Setup', 'DHCP Server', 'Wireless', and 'Change Password'. The main content area is titled 'Primary Setup [HELP]' and contains a table of settings:

Item	Setting
LAN IP Address	192.168.123.254
3G Failover	<input type="checkbox"/> Enable checking wired-WAN alive Internet host: <input type="text"/>
WAN Type	3G
APN	Internet
PIN Code	<input type="text"/>
Dialed Number	*99#
Account	<input type="text"/>
Password	<input type="text"/>
Authentication	<input checked="" type="radio"/> Auto <input type="radio"/> PAP <input type="radio"/> CHAP
Primary DNS	<input type="text"/>
Secondary DNS	<input type="text"/>
Connection Control	Auto Reconnect (always-on)
Maximum Idle Time	600 seconds
Keep Alive	<input checked="" type="radio"/> Disable <input type="radio"/> Use LCP Echo Request ↳ lcp-echo-interval: 10 seconds ↳ lcp-echo-failure: 3 times

At the bottom of the settings table are 'Save' and 'Undo' buttons.

1. **LAN IP Address:** the local IP address of this device. The computers on your network must use the LAN IP address of your product as their Default Gateway. You can change it if necessary.
2. **3G Failover:** The WAN type will be change to 3G automatically, if the internet host (to detect it by wired WAN) is defunct.
3. **WAN Type:** WAN connection type of your ISP. You can click WAN Type HSPA button to choose a correct one from the following options:

Static IP Address:

WAN IP Address, Subnet Mask, Gateway, Primary and Secondary DNS: enter the proper setting provided by your ISP.

Dynamic IP Address:

▶ Host Name	<input type="text"/> (optional)
▶ ISP registered MAC Address	<input type="text"/> <input type="button" value="Clone"/> <input type="button" value="Clear"/>
▶ Connection Control	Auto Reconnect (always-on) ▼
▶ NAT disable	<input type="checkbox"/> Enable

1. Host Name: optional, required by some ISPs, for example, @Home.
2. ISP registered MAC address: You can change the WAN port MAC address, it is your ISP assigned to you.
3. Connection Control: There are 3 modes to select:
 - Connect-on-demand: The device will link up with ISP when the clients send outgoing packets.
 - Auto Reconnect (Always-on): The device will link with ISP until the connection is established.
 - Manually: The device will not make the link until someone clicks the connect-button in the Status-page.
4. NAT disable: NAT disable is enabling, it can bridge data form WAN port to LAN port.

PPP over Ethernet

▶ PPPoE Account	<input type="text"/>
▶ PPPoE Password	<input type="text"/>
▶ Primary DNS	<input type="text"/>
▶ Secondary DNS	<input type="text"/>
▶ Connection Control	Connect-on-Demand ▼
▶ Maximum Idle Time	<input type="text" value="600"/> seconds
▶ PPPoE Service Name	<input type="text"/> (optional)
▶ Assigned IP Address	<input type="text"/> (optional)
▶ MTU	<input type="text" value="0"/> (0 is auto)
▶ NAT disable	<input type="checkbox"/> Enable

1. PPPoE Account and Password: the account and password your ISP assigned to you. For security, this field appears blank. If you don't want to change the password, leave it empty.
2. Connection Control: There are 3 modes to select:
 - Connect-on-demand: The device will link up with ISP when the clients send outgoing packets.
 - Auto Reconnect (Always-on): The device will link with ISP until the connection is established.
 - Manually: The device will not make the link until someone clicks the connect-button in the Status-page.
3. Maximum Idle Time: the amount of time of inactivity before disconnecting your PPPoE session. Set it to zero or enable Auto-reconnect to disable this feature.
4. PPPoE Service Name: optional. Input the service name if your ISP requires it. Otherwise, leave it blank.
5. MTU (Maximum Transmission Unit): Most ISP offers MTU value to users. The default value is 0 (Auto).
6. NAT disable: NAT disable is enabling, it can bridge data form WAN port to LAN port.

PPTP

▶ IP Mode	Dynamic IP Address ▾
▶ My IP Address	<input type="text"/>
▶ My Subnet Mask	<input type="text"/>
▶ Gateway IP	<input type="text"/>
▶ Server IP Address/Name	<input type="text"/>
▶ PPTP Account	<input type="text"/>
▶ PPTP Password	<input type="text"/>
▶ Connection ID	<input type="text"/> (optional)
▶ Maximum idle time	<input type="text" value="600"/> seconds
▶ Connection Control	Connect-on-Demand ▾
▶ MTU	<input type="text" value="0"/> (0 is auto)

First, please check your ISP assigned and Select Static IP Address or Dynamic IP Address. For example: Use Static, the private My IP address, My subnet mask and Gateway are your ISP assigned to you.

1. Server IP Address/Name: the IP address (or URL) of the PPTP server.
2. PPTP Account and Password: the account and password your ISP assigned to you. For security, this field appears blank. If you don't want to change the password, keep it empty.
3. Connection ID: optional. Input the connection ID if your ISP requires it.
4. Maximum Idle Time: the time of no activity to disconnect your PPTP session. Set it to zero or enable Auto-reconnect to disable this feature. If Auto-reconnect is enabled, this product will connect to ISP automatically, after system is restarted or connection is dropped.
5. Connection Control: There are 3 modes to select:
 - Connect-on-demand: The device will link up with ISP when the clients send outgoing packets.
 - Auto Reconnect (Always-on): The device will link with ISP until the connection is established.
 - Manually: The device will not make the link until someone clicks the connect-button in the Status-page.
6. MTU (Maximum Transmission Unit): Most ISP offers MTU value to users. The default value is 0 (Auto).

L2TP

▶ IP Mode	Dynamic IP Address ▾
▶ IP Address	<input type="text"/>
▶ Subnet Mask	<input type="text"/>
▶ WAN Gateway IP	<input type="text"/>
▶ Server IP Address/Name	<input type="text"/>
▶ L2TP Account	<input type="text"/>
▶ L2TP Password	<input type="text"/>
▶ Maximum idle time	<input type="text" value="600"/> seconds
▶ Connection Control	Connect-on-Demand ▾
▶ MTU	<input type="text" value="0"/> (0 is auto)

First, please check your ISP assigned and Select Static IP Address or Dynamic IP Address. For example: Use Static, the private IP address, subnet mask and WAN Gateway IP are your ISP assigned to you.

1. Server IP Address/Name: the IP address (or URL) of the L2TP server.
2. L2TP Account and Password: the account and password your ISP assigned to you. For security, this field appears blank. If you don't want to change the password, keep it empty.
3. Maximum Idle Time: the time of no activity to disconnect your L2TP session. Set it to zero or enable Auto-reconnect to disable this feature. If Auto-reconnect is enabled, this product will connect to ISP automatically, after system is restarted or connection is dropped.
4. Connection Control: There are 3 modes to select:
 - Connect-on-demand: The device will link up with ISP when the clients send outgoing packets.
 - Auto Reconnect (Always-on): The device will link with ISP until the connection is established.
 - Manually: The device will not make the link until someone clicks the connect-button in the Status-page.
5. MTU (Maximum Transmission Unit): Most ISP offers MTU value to users. The default value is 0 (Auto).

3G

▶ APN	Internet
▶ PIN Code	
▶ Dialed Number	*99#
▶ Account	
▶ Password	
▶ Authentication	<input checked="" type="radio"/> Auto <input type="radio"/> PAP <input type="radio"/> CHAP
▶ Primary DNS	
▶ Secondary DNS	
▶ Connection Control	Auto Reconnect (always-on) ▼
▶ Maximum Idle Time	600 seconds
▶ Keep Alive	<input checked="" type="radio"/> Disable <input type="radio"/> Use LCP Echo Request ▶ Icp-echo-interval: 10 seconds ▶ Icp-echo-failure: 3 times

For 3G WAN Networking. The WAN fields may not be necessary for your connection. The information on this page will only be used when your service provider requires you to enter a User Name and Password to connect to the 3G network.

註解 [08]: For..., the WAN...

Please refer to your documentation or service provider for additional information.

1. APN: Enter the APN for your PC card here.
2. Pin Code: Enter the Pin Code for your SIM card
3. Dial-Number: This field should not be altered except when required by your service provider.
4. User Name: Enter the new *User Name* for your PC card here.
5. Password: Enter the new *Password* for your PC card here.
6. Primary DNS: This feature allows you to assign a Primary DNS Server (Optional)
7. Secondary DNS: This feature allows you to assign a Secondary DNS Server (Optional)
8. Connection Control: There are 3 modes to select:
 - Connect on Demand: The device will link up with ISP when the clients send outgoing packets.
 - Auto Reconnect (always-on): The device will link with ISP until the connection is established.
 - Manually: The device will not make the link until someone clicks the connect-button in the Status-page.
9. Maximum Idle Time: The Connection will be broken when the idle time arrives.
10. Keep Alive: There are 2 modes to select:
 - Disable / Use LCP Echo Request.

3.2.1.2 DHCP Server

Item	Setting
DHCP Server	<input type="radio"/> Disable <input checked="" type="radio"/> Enable
IP Pool Starting Address	100
IP Pool Ending Address	200
Lease Time	86400 Seconds
Domain Name	

1. Press **“More>>”**, for more settings.
2. **DHCP Server:** Choose either **Disable** or **Enable**.
3. **IP Pool Starting/Ending Address:** Whenever there is a request, the DHCP server will automatically allocate an unused IP address from the IP address pool to the requesting computer. You must specify the starting / ending address of the IP address pool.
4. **Lease Time:** DHCP lease time to the DHCP client.
5. **Domain Name:** Optional, this information will be passed to the client
6. **Primary DNS/Secondary DNS:** Optional, This feature allows you to assign a DNS Servers
7. **Primary WINS/Secondary WINS:** Optional, this feature allows you to assign a WINS Servers
8. **Gateway:** Optional, Gateway Address would be the IP address of an alternate Gateway.
This function enables you to assign another gateway to your PC, when DHCP server offers an IP to your PC.
9. **Clients List...:** Reference the next Page “DHCP Clients List”.
10. **Fixed Mapping...:** Reference the next page “DHCP Fixed Mapping”.

After you finish your selection then

Either Click on **“Save”** to store what you just pick or click **“Undo”** to give up

註解 [09]: 應改爲
Press... for more....

註解 [010]: 應該爲
Refer to.....

註解 [011]: 應該爲
Refer to....

註解 [012]: 應該爲
After..., then.....

DHCP Clients List

WiFi Combo Broadband Gateway (R0.02)

ADMINISTRATOR's MAIN MENU | Status | Wizard | Advanced | Logout

BASIC SETTING | FORWARDING RULES | SECURITY SETTING | ADVANCED SETTING | TOOLBOX

- Primary Setup
- DHCP Server
- Wireless
- Change Password

DHCP Clients List

IP Address	Host Name	MAC Address	Type	Lease Time	Select
192.168.1.100	mychat-487abf9b	00-13-49-AA-03-17	Wired	22:26:15	<input type="checkbox"/>

Delete | Back | Refresh | Fixed Mapping

Delete: The selected items will be deleted.

Fixed Mapping: The selected items will be added to the Fix Mapping Table.

DHCP Fixed Mapping

The DHCP server will reserve the IP address for the Client, which have the MAC address.

WiFi Combo Broadband Gateway (R0.02)

ADMINISTRATOR's MAIN MENU | Status | Wizard | Advanced | Logout

BASIC SETTING | FORWARDING RULES | SECURITY SETTING | ADVANCED SETTING | TOOLBOX

- Primary Setup
- DHCP Server
- Wireless
- Change Password

Fixed Mapping

DHCP clients: -- select one -- | Copy to: ID --

ID	MAC Address	IP Address	Enable
1	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
2	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
3	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
4	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
5	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
6	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
7	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
8	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
9	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
10	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>

<< Previous | Next >> | Save | Undo | Back

註解 [013]: 應該為 has

3.2.1.3 Wireless Settings

The screenshot shows the configuration interface for a WiFi Combo Broadband Gateway (R0.02). The main menu includes: ADMINISTRATOR's MAIN MENU, Status, Wizard, Advanced, and Logout. The sub-menu includes: BASIC SETTING, FORWARDING RULES, SECURITY SETTING, ADVANCED SETTING, and TOOLBOX. The left sidebar shows: Primary Setup, DHCP Server, Wireless, and Change Password. The main content area is titled 'Wireless Setting' and contains the following table:

Item	Setting
Wireless Module	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Network ID(SSID)	default
SSID Broadcast	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Channel	11
Wireless Mode	B/G/N mixed
Authentication	Auto
802.1X	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Encryption	None

Buttons at the bottom: Save, Undo, WDS Setting..., WPS Setup..., Wireless Client List..

Wireless settings allow you to set the wireless configuration items.

1. **Wireless:** *Enabled* is the default. Selecting this option will allow you to set your Wireless Access Point (WAP) settings.
2. **Network ID (SSID):** Service Set Identifier (SSID) is the name designated for a specific wireless local area network (WLAN). The SSID's factory default setting is *default*. The SSID can be easily changed to establish a new wireless network. (Note: SSID names may contain up to 32 ASCII characters).
3. **SSID Broadcast:** The gateway will broadcast beacons that have some information, including ssid so that wireless clients can know how many AP devices by scanning function in the network. Therefore, this function is disabled; the wireless clients can not find the device from beacons.
4. **Channel:** *Auto* is the default. Devices on the network must share the same channel. (Note: Wireless adapters automatically scan and match the wireless settings. You may also select the channel you wish to use).
5. **Wireless Mode:** Choose *B/G Mixed*, *B only*, *G only*, *N only*, *G/N Mixed* or *B/G/N mixed*. The factory default setting is *B/G/N mixed*.
6. **Authentication:** You may select from nine kinds of authentication to secure your wireless network: Open, Shared, Auto, WPA-PSK, WPA, WPA2-PSK, WPA2, WPA-PSK/WPA2-PSK, WPA/WPA2.

Open

Open system authentication simply consists of two communications. The first is an authentication request by the client that contains the station ID (typically the MAC address). This is followed by an authentication response from the AP/gateway containing a success or failure message. An example of when a failure may occur is if the client's MAC address is explicitly excluded in the AP/gateway configuration.

Shared

Shared key authentication relies on the fact that both stations taking part in the authentication process have the same "shared" key or passphrase. The shared key is manually set on both the client station and the AP/gateway. Three types of shared key authentication are available today for home or small office WLAN environments.

Auto

The AP will select the Open or Shared by the client's request automatically.

WPA-PSK

Select Encryption and Pre-share Key Mode

If you select HEX, you have to fill in 64 hexadecimal (0, 1, 2...8, 9, A, B...F) digits.

If you select ASCII, the length of pre-share key is from 8 to 63.

Fill in the key, Ex 12345678

WPA

Check Box was used to switch the function of the WPA. When the WPA function is enabled, the Wireless user must **authenticate** to this gateway first to use the Network service. RADIUS Server IP address or the 802.1X server's domain-name.

Select Encryption and RADIUS Shared Key

If you select HEX, you have to fill in 64 hexadecimal (0, 1, 2...8, 9, A, B...F) digits

If you select ASCII, the length of pre-share key is from 8 to 63.

Key value shared by the RADIUS server and this gateway. This key value is consistent with the key value in the RADIUS server.

WPA-PSK2

WPA-PSK2 uses AES and TKIP for encryption, the others are same the WPA-PSK.

註解 [014]: 應改為 are same with

WPA2

WPA2 adds AES and TKIP for encryption, the others are same the WPA.

WPA-PSK/WPA-PSK2

Another encryption options for WPA-PSK-TKIP and WPA-PSK2-AES, the others are same the WPA-PSK.

註解 [015]: 應改為 are same with

WPA/WPA2

Another encryption options for WPA-TKIP and WPA2-AES, the others are same the WPA.

註解 [016]: 應改為 are same with

WDS (Wireless Distribution System) Setting

WDS operation as defined by the IEEE802.11 standard has been made available. Using WDS it is possible to wirelessly connect Access Points, and in doing so extend a wired infrastructure to locations where cabling is not possible or inefficient to implement.

The screenshot shows the 'WDS Setting' configuration page. The interface includes a top navigation bar with 'ADMINISTRATOR'S MAIN MENU', 'Status', 'Wizard', 'Advanced', and 'Logout'. Below this is a secondary navigation bar with 'BASIC SETTING', 'FORWARDING RULES', 'SECURITY SETTING', 'ADVANCED SETTING', and 'TOOLBOX'. A left sidebar contains a tree view with 'Primary Setup', 'DHCP Server', 'Wireless', and 'Change Password'. The main content area is titled 'WDS Setting' and contains a table with the following items and settings:

Item	Setting
Wireless Bridging	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Remote AP MAC 1	<input type="text"/>
Remote AP MAC 2	<input type="text"/>
Remote AP MAC 3	<input type="text"/>
Remote AP MAC 4	<input type="text"/>
Encryption type	WEP
Encryption key	<input type="text"/>

At the bottom of the table are three buttons: 'Save', 'Undo', and 'Back'. A '[HELP]' link is located in the top right corner of the table area.

WPS (Wi-Fi Protection Setup)

WPS is Wi-Fi Protection Setup which is similar to WCN-NET and offers safe and easy way in Wireless Connection.

The screenshot shows the 'Wi-Fi Protected Setup' configuration page. The interface is identical to the WDS setting page. The main content area is titled 'Wi-Fi Protected Setup' and contains a table with the following items and settings:

Item	Setting
WPS	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
AP PIN	11553366 <input type="button" value="Generate New PIN"/>
Config Mode	Enrollee
Config Status	UNCONFIGURED <input type="button" value="Set"/>
Config Method	Push Button
WPS status	STARTPROCESS

At the bottom of the table are three buttons: 'Save', 'Trigger', and 'Cancel'.

Wireless Client List

The list of wireless client is **shows** here.

註解 [017]: 應改為 shown



3.2.1.4 Change Password



You can change Password here. We **strongly** recommend you to change the system password for security reason.

Click on “Save” to store what you just select or “Undo” to give up

3.2.2 Forwarding Rules

The screenshot displays the configuration interface for a WiFi Combo Broadband Gateway (R0.02). The interface is organized into several sections:

- Header:** WiFi Combo Broadband Gateway (R0.02)
- Navigation Bar:** ADMINISTRATOR's MAIN MENU, Status, Wizard, Advanced, Logout
- Menu Bar:** BASIC SETTING, FORWARDING RULES (selected), SECURITY SETTING, ADVANCED SETTING, TOOLBOX
- Left Sidebar:** Virtual Server, Special AP, Miscellaneous
- Main Content Area:** Forwarding Rules
 - Virtual Server**
 - Allows others to access WWW, FTP, and other services on your LAN.
 - Special Application**
 - This configuration allows some applications to connect, and work with the NAT router.
 - Miscellaneous**
 - IP Address of DMZ Host: Allows a computer to be exposed to unrestricted 2-way communication. Note that, this feature should be used only when needed.
 - UPnP Setting: If you enable UPnP function, the router will work with UPnP devices/software.

3.2.2.1 Virtual Server

WiFi Combo Broadband Gateway (R0.02)

ADMINISTRATOR's MAIN MENU | Status | Wizard | Advanced | Logout

BASIC SETTING | FORWARDING RULES | SECURITY SETTING | ADVANCED SETTING | TOOLBOX

Virtual Server [HELP]

Well known services -- select one -- Copy to ID --

ID	Service Ports	Server IP	Enable	Use Rule#
1	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always
2	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always
3	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always
4	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always
5	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always
6	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always
7	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always
8	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always
9	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always
10	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always
11	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always
12	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always
13	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always
14	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always
15	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always
16	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always
17	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always
18	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always
19	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always
20	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	(0) Always

Save Undo

This product's NAT firewall filters out unrecognized packets to protect your Intranet, so all hosts behind this product are invisible to the outside world. If you wish, you can make some of them accessible by enabling the Virtual Server Mapping.

A virtual server is defined as a Service Port, and all requests to this port will be redirected to the computer specified by the Server IP. Virtual Server can work with Scheduling Rules, and give user more flexibility on Access control. For Detail, please refer to Scheduling Rule.

註解 [018]: 字尾加上 s

For example, if you have an FTP server (port 21) at 192.168.123.1 and Scheduling Rule(0), a Web server (port 80) at 192.168.123.2 and Scheduling Rule(1), a VPN server at 192.168.123.6 and Scheduling Rule(2), then you need to specify the following virtual server mapping table:

Service Port	Server IP	Enable	Scheduling Rule
21	192.168.123.1	V	0
80	192.168.123.2	V	1
1723	192.168.123.6	V	2

Click on “Save” to store what you just select or “Undo” to give up

3.2.2.2 Special AP

WiFi Combo Broadband Gateway (R0.02)

ADMINISTRATOR's MAIN MENU | Status | Wizard | Advanced | Logout

BASIC SETTING | FORWARDING RULES | SECURITY SETTING | ADVANCED SETTING | TOOLBOX

Virtual Server
Special AP
Miscellaneous

Special Applications [HELP]

Popular applications --select one-- Copy to ID --

ID	Trigger	Incoming Ports	Enable
1	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
2	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
3	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
4	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
5	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
6	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
7	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
8	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>

Save Undo

Some applications require multiple connections, like Internet games, Video conferencing, Internet telephony, etc. Because of the firewall function, these applications cannot work with a pure NAT router. The Special Applications feature allows some of these applications to work with this product. If the mechanism of Special Applications fails to make an application work, try setting your computer as the DMZ host instead.

1. **Trigger:** the outbound port number issued by the application.
2. **Incoming Ports:** when the trigger packet is detected, the inbound packets sent to the specified port numbers are allowed to pass through the firewall.


This product provides some predefined settings.

1. Select your application and
2. Click “Copy to” to add the predefined setting to your list.

Note! At any given time, only one PC can use each Special Application tunnel.

Click on “Save” to store what you just select or” Undo” to give up

3.2.2.3 Miscellaneous



1. IP Address of DMZ Host

DMZ (Demilitarized Zone) Host is a host without the protection of firewall. It allows a computer to be exposed to unrestricted 2-way communication for Internet games, Video conferencing, Internet telephony and other special applications.

2. UPnP Setting

The device also supports this function. If the OS supports this function enable it, like Windows XP. When the user gets IP from Device and will see icon as below:



註解 [019]: 刪除 and 改為....., they




Click on "Save" to store what you just select or "Undo" to give up

3.2.3 Security Setting

The screenshot displays the administrator interface for a WiFi Combo Broadband Gateway (R0.02). The top navigation bar includes 'ADMINISTRATOR's MAIN MENU', 'Status', 'Wizard', 'Advanced', and 'Logout'. Below this, a secondary menu highlights 'BASIC SETTING', 'FORWARDING RULES', 'SECURITY SETTING', 'ADVANCED SETTING', and 'TOOLBOX'. A left sidebar lists navigation options: Status, Packet Filters, Domain Filters, URL Blocking, MAC Control, and Miscellaneous. The main content area is titled 'Security Setting' and contains the following information:

- Packet Filters**
 - Allows you to control access to a network by analyzing the incoming and outgoing packets and letting them pass or halting them based on the IP address of the source and destination.
- Domain Filters**
 - Let you prevent users under this device from accessing specific URLs.
- URL Blocking**
 - URL Blocking will block LAN computers to connect to pre-defined websites.
- MAC Address Control**
 - MAC Address Control allows you to assign different access right for different users and to assign a specific IP address to a certain MAC address.
- Miscellaneous**
 - Remote Administrator Host: In general, only Intranet user can browse the built-in web pages to perform administration task. This feature enables you to perform administration task from remote host.
 - Administrator Time-out: The amount of time of inactivity before the device will automatically close the Administrator session. Set this to zero to disable it.
 - Discard PING from WAN side: When this feature is enabled, hosts on the WAN cannot ping the Device.

3.2.3.1 Packet Filters (Outbound & Inbound))



Packet Filter includes both outbound filter and inbound filter. And they have same way to setting. Packet Filter enables you to control what packets are allowed to pass the gateway. Outbound filter applies on all outbound packets. However, inbound filter applies on packets that destined to Virtual Servers or DMZ host only. You can select one of the two filtering policies:

註解 [020]: 應改為 the same

1. Allow all to pass except those match the specified rules
2. Deny all to pass except those match the specified rules

You can specify 8 rules for each direction: inbound or outbound. For each rule, you can define the following:

- Source IP address
- Source port
- Destination IP address
- Destination port
- Protocol: TCP or UDP or both.
- Use Rule#

For source or destination IP address, you can define a single IP address (4.3.2.1) or a range of IP addresses (4.3.2.1-4.3.2.254). An empty implies all IP addresses.

For source or destination port, you can define a single port (80) or a range of ports (1000-1999). Add prefix "T" or "U" to specify TCP or UDP protocol. For example, T80, U53, U2000-2999, No prefix indicates both TCP and UDP are defined. An empty implies all port addresses. Packet Filter can work with Scheduling Rules, and give user more flexibility on Access control. For Detail, please refer to Scheduling Rule.

Each rule can be enabled or disabled individually.

Click on “Save” to store what you just select or “Undo” to give up

3.2.3.2 Domain Filters

WiFi Combo Broadband Gateway (R0.02)

ADMINISTRATOR's MAIN MENU Status Wizard Advanced Logout

BASIC SETTING FORWARDING RULES SECURITY SETTING ADVANCED SETTING TOOLBOX

- Status
- Packet Filters
- Domain Filters
- URL Blocking
- MAC Control
- Miscellaneous

[HELP]

Item	Setting
▶ Domain Filter	<input type="checkbox"/> Enable
▶ Log DNS Query	<input type="checkbox"/> Enable
▶ Privilege IP Addresses Range	From <input type="text"/> To <input type="text"/>

ID	Domain Suffix	Action	Enable
1	<input type="text"/>	<input type="checkbox"/> Drop <input type="checkbox"/> Log	<input type="checkbox"/>
2	<input type="text"/>	<input type="checkbox"/> Drop <input type="checkbox"/> Log	<input type="checkbox"/>
3	<input type="text"/>	<input type="checkbox"/> Drop <input type="checkbox"/> Log	<input type="checkbox"/>
4	<input type="text"/>	<input type="checkbox"/> Drop <input type="checkbox"/> Log	<input type="checkbox"/>
5	<input type="text"/>	<input type="checkbox"/> Drop <input type="checkbox"/> Log	<input type="checkbox"/>
6	<input type="text"/>	<input type="checkbox"/> Drop <input type="checkbox"/> Log	<input type="checkbox"/>
7	<input type="text"/>	<input type="checkbox"/> Drop <input type="checkbox"/> Log	<input type="checkbox"/>
8	<input type="text"/>	<input type="checkbox"/> Drop <input type="checkbox"/> Log	<input type="checkbox"/>
9	<input type="text"/>	<input type="checkbox"/> Drop <input type="checkbox"/> Log	<input type="checkbox"/>
10	* (all others)	<input type="checkbox"/> Drop <input type="checkbox"/> Log	-

Save Undo

1. **Domain Filter**
Let you prevent users under this device from accessing specific URLs.
2. **Domain Filter Enable**
Check if you want to enable Domain Filter.
3. **Log DNS Query**
Check if you want to log the action when someone accesses the specific URLs.
4. **Privilege IP Address Range**
Setting a group of hosts and privilege these hosts to access network without restriction.
5. **Domain Suffix**
A suffix of URL can be restricted, for example, ".com", and "xxx.com".
6. **Action**
When someone is accessing the URL met the domain-suffix, what kind of action you want. Check "log" to log these access.
7. **Enable**
Check to enable each rule.

Click on "Save" to store what you just select or "Undo" to give up

3.2.3.3 URL Blocking

URL Blocking [HELP]		
Item	Setting	
▶ URL Blocking	<input type="checkbox"/> Enable	
ID	URL	Enable
1	<input type="text"/>	<input type="checkbox"/>
2	<input type="text"/>	<input type="checkbox"/>
3	<input type="text"/>	<input type="checkbox"/>
4	<input type="text"/>	<input type="checkbox"/>
5	<input type="text"/>	<input type="checkbox"/>
6	<input type="text"/>	<input type="checkbox"/>
7	<input type="text"/>	<input type="checkbox"/>
8	<input type="text"/>	<input type="checkbox"/>
9	<input type="text"/>	<input type="checkbox"/>
10	<input type="text"/>	<input type="checkbox"/>

URL Blocking will block LAN computers to connect to pre-define Websites. The major difference between “Domain filter” and “URL Blocking” is Domain filter require user to input suffix (like .com or .org, etc), while URL Blocking require user to input a keyword only. In other words, Domain filter can block specific website, while URL Blocking can block hundreds of websites by simply a keyword.

1. **URL Blocking Enable**

Check if you want to enable URL Blocking.

2. **URL**

If any **part** of the Website's URL **matches** the pre-defined word, the connection will be blocked.

For example, you can use pre-defined word "sex" to block all websites if their URLs contain pre-defined word "sex".

3. **Enable**

Check to enable each rule.

註解 [021]: 字尾加上 s

註解 [022]: 刪除 s

Click on “Save” to store what you just select or “Undo” to give up

3.2.3.4 MAC Control

The screenshot shows the 'MAC Address Control' configuration page. The 'Enable' checkbox is unchecked. Under 'Connection control', the 'allow' dropdown is selected. Under 'Association control', the 'allow' dropdown is selected. The DHCP clients table has 5 rows with empty input fields for MAC and IP addresses, and checkboxes for 'C' and 'A'.

Item	Setting			
MAC Address Control	<input type="checkbox"/> Enable			
<input type="checkbox"/> Connection control	Wireless and wired clients with C checked can connect to this device; and allow unspecified MAC addresses to connect.			
<input type="checkbox"/> Association control	Wireless clients with A checked can associate to the wireless LAN; and allow unspecified MAC addresses to associate.			
DHCP clients --select one-- <input type="button" value="Copy to"/> ID --				
ID	MAC Address	IP Address	C	A
1	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	<input type="checkbox"/>
2	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	<input type="checkbox"/>
5	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>	<input type="checkbox"/>

MAC Address Control allows you to assign different access right for different users and to assign a specific IP address to a certain MAC address.

1. MAC Address Control

Check "Enable" to enable the "MAC Address Control". All of the settings in this page will take effect only when "Enable" is checked.

2. Connection control

Check "Connection control" to enable the controlling of which wired and wireless clients can connect to this device. If a client is denied to connect to this device, it means the client can't access to the Internet either. Choose "allow" or "deny" to allow or deny the clients, whose MAC addresses are not in the "Control table" (please see below), to connect to this device.

3. Association control

Check "Association control" to enable the controlling of which wireless client can associate to the wireless LAN. If a client is denied to associate to the wireless LAN, it means the client can't send or receive any data via this device. Choose "allow" or "deny" to allow or deny the clients, whose MAC addresses are not in the "Control table", to associate to the wireless LAN

**Click on "Save" to store what you just select or "Undo" to give up
Click on "Next Page" to go down or "Previous page" back to last page**

註解 [023]: 刪除逗點且應該為小寫 choose

註解 [024]: 應改為 controllable

3.2.3.5 Miscellaneous

Miscellaneous Items [HELP]		
Item	Setting	Enable
▶ Administrator Time-out	300 seconds (0 to disable)	
▶ Remote Administrator Host : Port	<input type="text"/> / <input type="text"/> : <input type="text"/>	<input type="checkbox"/>
▶ Discard PING from WAN side		<input type="checkbox"/>
▶ DoS Attack Detection		<input type="checkbox"/>

Save Undo

1. **Administrator Time-out**
The time of no activity to logout automatically, you may set it to zero to disable this feature.
2. **Remote Administrator Host/Port**
In general, only Intranet user can browse the built-in web pages to perform administration task. This feature enables you to perform administration task from remote host. If this feature is enabled, only the specified IP address can perform remote administration. If the specified IP address is 0.0.0.0, any host can connect to this product to perform administration task. You can use subnet mask bits "/nn" notation to specified a group of trusted IP addresses for example, "10.1.2.0/24". NOTE: When Remote Administration is enabled, the web server port will be shifted to 80. You can change web server port to other port, too.
3. **Discard PING from WAN side**
When this feature is enabled, any host on the WAN cannot ping this product.
4. **DoS Attack Detection**
When this feature is enabled, the gateway will detect and log the DoS attack comes from the Internet. Currently, the gateway can detect the following DoS attack: SYN Attack, Win Nuke, Port Scan, Ping of Death, Land Attack etc.

註解 [025]: 應改爲 coming

Click on "Save" to store what you just select or "Undo" to give up

3.2.4 Advanced Setting

The screenshot displays the 'Advanced Setting' page of a WiFi Combo Broadband Gateway (R0.02). The interface includes a top navigation bar with 'ADMINISTRATOR's MAIN MENU', 'Status', 'Wizard', 'Advanced', and 'Logout'. Below this is a secondary menu with 'BASIC SETTING', 'FORWARDING RULES', 'SECURITY SETTING', 'ADVANCED SETTING', and 'TOOLBOX'. A left sidebar lists various settings: Status, System Log, Dynamic DNS, QoS, SNMP, Routing, System Time, and Scheduling. The main content area, titled 'Advanced Setting', contains the following list of items:

- **System Log**
 - Send system log to a dedicated host or email to specific receipts.
- **Dynamic DNS**
 - To host your server on a changing IP address, you have to use dynamic domain name service (DDNS).
- **QoS Rule**
 - Quality of Service can provide different priority to different users or data flows, or guarantee a certain level of performance.
- **SNMP**
 - Gives a user the capability to remotely manage a computer network by polling and setting terminal values and monitoring network events.
- **Routing**
 - If you have more than one routers and subnets, you may want to enable routing table to allow packets to find proper routing path and allow different subnets to communicate with each other.
- **System Time**
 - Allow you to set device time manually or consult network time from NTP server.
- **Schedule Rule**
 - Apply schedule rules to Packet Filters and Virtual Server.

3.2.4.1 System Log

Item	Setting	Enable
▶ IP address for syslogd	<input type="text"/>	<input type="checkbox"/>
▶ Setting of Email alert		<input type="checkbox"/>
• SMTP Server: port	<input type="text"/> : <input type="text"/>	
• SMTP Username	<input type="text"/>	
• SMTP Password	<input type="text"/>	
• E-mail addresses	<input type="text"/>	
• E-mail subject	<input type="text"/>	

This page supports two methods to export system logs to specific destination by means of syslog (UDP) and SMTP (TCP). The items you have to setup including:

註解 [026]: 應改爲

1. **IP Address for Syslog**

Host IP of destination where syslog will be sent to.
Check **Enable** to enable this function.

2. **E-mail Alert Enable**

Check if you want to enable Email alert (send syslog via email).

- A. **SMTP Server IP and Port**

Input the SMTP server IP and port, which are concated with '!'. If you do not specify port number, the default value is 25.

For example, "mail.your_url.com" or "192.168.1.100:26".

- B. **SMTP Username/Password**

The username and password login the SMTP server.

- C. **E-mail address**

The recipients who will receive these logs, you can assign more than 1 recipient, using ';' or ',' to separate these email addresses.

- D. **E-mail Subject**

The subject of email alert, this setting is optional.

3. **View Log...:**

Reference the [Section 3.2.5.1 System Info](#).

註解 [027]: 應改爲

Click on "Save" to store what you just select or "Undo" to give up

3.2.4.2 Dynamic DNS

The screenshot shows the 'Dynamic DNS' configuration page. The table below represents the data visible in the interface:

Item	Setting
DDNS	<input checked="" type="radio"/> Disable <input type="radio"/> Enable
Provider	DynDNS.org(Dynamic)
Host Name	<input type="text"/>
Username / E-mail	<input type="text"/>
Password / Key	<input type="text"/>

Buttons: Save, Undo

To host your server on a changing IP address, you have to use dynamic domain name service (DDNS). So that anyone wishing to reach your host only needs to know the name of it. Dynamic DNS will map the name of your host to your current IP address, which changes each time you connect your Internet service provider.

註解 [028]: 應改為 Therefore.

Before you enable Dynamic DNS, you need to register an account on one of these Dynamic DNS servers that we list in provider field.

To enable Dynamic DNS click the check box next to Enable in the DDNS field.

Next you can enter the appropriate information about your Dynamic DNS Server.

You have to define:

Provider

Host Name

Username/E-mail

Password/Key

You will get this information when you register an account on a Dynamic DNS server.

Click on “Save” to store what you just select or “Undo” to give up

3.2.4.3 QoS

WiFi Combo Broadband Gateway (R0.02)

ADMINISTRATOR'S MAIN MENU Status Wizard Advanced Logout

BASIC SETTING FORWARDING RULES SECURITY SETTING **ADVANCED SETTING** TOOLBOX

QoS Rule

Item	Setting				
QoS Control	<input type="checkbox"/> Enable				
Bandwidth of Upstream	<input type="text"/> kbps (Kilobits per second)				
ID	Local IP : Ports	Remote IP : Ports	QoS Priority	Enable	Use Rule#
1	<input type="text"/> : <input type="text"/>	<input type="text"/> : <input type="text"/>	High	<input type="checkbox"/>	(0) Always
2	<input type="text"/> : <input type="text"/>	<input type="text"/> : <input type="text"/>	High	<input type="checkbox"/>	(0) Always
3	<input type="text"/> : <input type="text"/>	<input type="text"/> : <input type="text"/>	High	<input type="checkbox"/>	(0) Always
4	<input type="text"/> : <input type="text"/>	<input type="text"/> : <input type="text"/>	High	<input type="checkbox"/>	(0) Always
5	<input type="text"/> : <input type="text"/>	<input type="text"/> : <input type="text"/>	High	<input type="checkbox"/>	(0) Always
6	<input type="text"/> : <input type="text"/>	<input type="text"/> : <input type="text"/>	High	<input type="checkbox"/>	(0) Always
7	<input type="text"/> : <input type="text"/>	<input type="text"/> : <input type="text"/>	High	<input type="checkbox"/>	(0) Always
8	<input type="text"/> : <input type="text"/>	<input type="text"/> : <input type="text"/>	High	<input type="checkbox"/>	(0) Always

Save Undo

Provide different priority to different users or data flows, or guarantee a certain level of performance.

1. **Enable**
This Item enables QoS function or not.
2. **Bandwidth of Upstream**
Set the limitation of upstream speed.
3. **Local: IP**
Define the Local IP address of packets here.
4. **Local: Ports**
Define the Local port of the packets in this field.
5. **Remote: IP**
Define the Remote IP address of packets here.
6. **Remote: Ports**
Define the Remote port of the packets in this field.
7. **QoS Priority**
This defines the priority level of the current Policy Configuration. Packets associated with this policy will be serviced based upon the priority level set. For critical applications High or Normal levels are recommended. For non-critical applications select a Low level.
8. **User Rule#**
The QoS item can work with Scheduling Rule number#. Please reference the section 4.7.7 schedule.

註解 [029]: 刪除

註解 [030]: 應改爲 refer to

Click on “Save” to store what you just select or “Undo” to give up

3.2.4.4 SNMP

The screenshot shows the administrator interface for a WiFi Combo Broadband Gateway (R0.02). The top navigation bar includes 'ADMINISTRATOR's MAIN MENU', 'Status', 'Wizard', 'Advanced', and 'Logout'. Below this, there are tabs for 'BASIC SETTING', 'FORWARDING RULES', 'SECURITY SETTING', 'ADVANCED SETTING', and 'TOOLBOX'. The left sidebar contains a list of menu items: Status, System Log, Dynamic DNS, QoS, SNMP, Routing, System Time, and Scheduling. The main content area displays the 'SNMP Setting' page with a table of configuration options.

Item	Setting
▶ Enable SNMP	<input type="checkbox"/> Local <input type="checkbox"/> Remote
▶ Get Community	<input type="text"/>
▶ Set Community	<input type="text"/>
▶ IP 1	<input type="text"/>
▶ IP 2	<input type="text"/>
▶ IP 3	<input type="text"/>
▶ IP 4	<input type="text"/>
▶ SNMP Version	<input checked="" type="radio"/> V1 <input type="radio"/> V2c
▶ WAN Access IP Address	<input type="text"/>

At the bottom of the table, there are 'Save' and 'Undo' buttons.

In brief, SNMP, the Simple Network Management Protocol, is a protocol designed to give a user the capability to remotely manage a computer network by polling and setting terminal values and monitoring network events.

1. Enable SNMP

You must check Local, Remote or both to enable SNMP function. If Local is checked, this device will response request from LAN. If Remote is checked, this device will response request from WAN.

2. Get Community

Setting the community of Get Request your device will response.

3. Set Community

Setting the community of Set Request your device will accept.

IP 1, IP 2, IP 3, IP 4

Input your SNMP Management PC's IP here. User has to configure to where this device should send SNMP Trap message.

4. SNMP Version

Please select proper SNMP Version that your SNMP Management software supports.

5. WAN Access IP Address

If the user wants to limit to specific the IP address to access, please input in the item. The default 0.0.0.0 and means every IP of Internet can get some information of device with SNMP protocol.

註解 [031]: 删除 and

Click on "Save" to store what you just select or "Undo" to give up.

3.2.4.5 Routing

WiFi Combo Broadband Gateway (R0.02)

ADMINISTRATOR'S MAIN MENU | Status | Wizard | Advanced | Logout

BASIC SETTING | FORWARDING RULES | SECURITY SETTING | **ADVANCED SETTING** | TOOLBOX

- Status
- System Log
- Dynamic DNS
- QoS
- SNMP
- Routing**
- System Time
- Scheduling

Routing Table [HELP]

Item	Setting
Dynamic Routing	<input checked="" type="radio"/> Disable <input type="radio"/> RIPv1 <input type="radio"/> RIPv2
Static Routing	<input checked="" type="radio"/> Disable <input type="radio"/> Enable

ID	Destination	Subnet Mask	Gateway	Hop	Enable
1	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
2	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
3	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
4	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
5	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
6	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
7	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>
8	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>

1. **Routing Tables**

Allow you to determine which physical interface address to use for outgoing IP data grams. If you have more than one routers and subnets, you will need to enable routing table to allow packets to find proper routing path and allow different subnets to communicate with each other.

Routing Table settings are settings used to setup the functions of static and dynamic routing.

2. **Dynamic Routing**

Routing Information Protocol (RIP) will exchange information about destinations for computing routes throughout the network. Please select RIPv2 only if you have different subnet in your network. Otherwise, please select RIPv1 if you need this protocol.

3. **Static Routing**

For static routing, you can specify up to 8 routing rules. You can enter the destination IP address, subnet mask, gateway, hop for each routing rule, and then enable or disable the rule by checking or un-checking the Enable checkbox.

Click on “Save” to store what you just select or “Undo” to give up.

3.2.4.6 System Time

WiFi Combo Broadband Gateway (R0.02)

ADMINISTRATOR'S MAIN MENU | Status | Wizard | Advanced | Logout

BASIC SETTING | FORWARDING RULES | SECURITY SETTING | **ADVANCED SETTING** | TOOLBOX

- Status
- System Log
- Dynamic DNS
- QoS
- SNMP
- Routing
- System Time**
- Scheduling

Item	Setting
Time Zone	(GMT+08:00) Beijing, Chongqing, Hong Kong, Urumqi
Auto-Synchronization	<input checked="" type="checkbox"/> Enable Time Server (RFC-868): Auto

Save Undo

Sync with Time Server Sync with my PC (Sunday July 12, 2009 23:58:25)

- 1. Time Zone**
Select a time zone where this device locates.
- 2. Time Server**
Select a NTP time server to consult UTC time
- 3. Auto-Synchronization**
Select the "Enable" item to enable this function.
- 4. Sync with Time Server**
Select if you want to set Date and Time by NTP Protocol.
- 5. Sync with my PC**
Select if you want to set Date and Time using PC's Date and Time

Click on "Save" to store what you just select or "Undo" to give up.

3.2.4.7 Scheduling

WiFi Combo Broadband Gateway (R0.02)

ADMINISTRATOR's MAIN MENU
Status Wizard Advanced Logout

BASIC SETTING
FORWARDING RULES SECURITY SETTING ADVANCED SETTING TOOLBOX

- Status
- System Log
- Dynamic DNS
- QoS
- SNMP
- Routing
- System Time
- Scheduling

Schedule Rule Setting
[HELP]

Item	Setting		
▶ Name of Rule 1	<input style="width: 90%;" type="text"/>		
▶ Policy	Inactivate <input type="button" value="v"/> except the selected days and hours below.		
ID	Week Day	Start Time (hh:mm)	End Time (hh:mm)
1	<input type="button" value="-- choose one --"/>	<input style="width: 50%;" type="text"/>	<input style="width: 50%;" type="text"/>
2	<input type="button" value="-- choose one --"/>	<input style="width: 50%;" type="text"/>	<input style="width: 50%;" type="text"/>
3	<input type="button" value="-- choose one --"/>	<input style="width: 50%;" type="text"/>	<input style="width: 50%;" type="text"/>
4	<input type="button" value="-- choose one --"/>	<input style="width: 50%;" type="text"/>	<input style="width: 50%;" type="text"/>
5	<input type="button" value="-- choose one --"/>	<input style="width: 50%;" type="text"/>	<input style="width: 50%;" type="text"/>
6	<input type="button" value="-- choose one --"/>	<input style="width: 50%;" type="text"/>	<input style="width: 50%;" type="text"/>
7	<input type="button" value="-- choose one --"/>	<input style="width: 50%;" type="text"/>	<input style="width: 50%;" type="text"/>
8	<input type="button" value="-- choose one --"/>	<input style="width: 50%;" type="text"/>	<input style="width: 50%;" type="text"/>

You can set the schedule time to decide which service will be turned on or off. Select the "Enable" item. Press "Add New Rule" You can write a rule name and set which day and what time to schedule from "Start Time" to "End Time". The following example configure "ftp time" as "The ftp Protocol can be run everyday 14:10 to 16:20".

Click on "Save" to store what you just select.

WiFi Combo Broadband Gateway (R0.02)

ADMINISTRATOR'S MAIN MENU

Status

Wizard

Advanced

Logout

BASIC SETTING

FORWARDING RULES

SECURITY SETTING

ADVANCED SETTING

TOOLBOX

- Status
- System Log
- Dynamic DNS
- QoS
- SNMP
- Routing
- System Time
- Scheduling

Schedule Rule Setting [HELP]

Item		Setting	
▶ Name of Rule 1		<input type="text" value="ftp time"/>	
▶ Policy		Inactivate <input type="button" value="v"/> except the selected days and hours below.	
ID	Week Day	Start Time (hh:mm)	End Time (hh:mm)
1	<input type="button" value="v"/> Every Day	<input type="text" value="14:10"/>	<input type="text" value="16:20"/>
2	<input type="button" value="v"/> -- choose one --	<input type="text"/>	<input type="text"/>
3	<input type="button" value="v"/> -- choose one --	<input type="text"/>	<input type="text"/>
4	<input type="button" value="v"/> -- choose one --	<input type="text"/>	<input type="text"/>
5	<input type="button" value="v"/> -- choose one --	<input type="text"/>	<input type="text"/>
6	<input type="button" value="v"/> -- choose one --	<input type="text"/>	<input type="text"/>
7	<input type="button" value="v"/> -- choose one --	<input type="text"/>	<input type="text"/>
8	<input type="button" value="v"/> -- choose one --	<input type="text"/>	<input type="text"/>

3.2.5 Tool Box

The screenshot displays the administrator interface for a WiFi Combo Broadband Gateway (R0.02). The interface includes a top navigation bar with 'ADMINISTRATOR's MAIN MENU', 'Status', 'Wizard', 'Advanced', and 'Logout'. Below this is a secondary menu with 'BASIC SETTING', 'FORWARDING RULES', 'SECURITY SETTING', 'ADVANCED SETTING', and 'TOOLBOX'. The 'TOOLBOX' menu is selected, showing a list of options: View Log, Firmware Upgrade, Backup Setting, Reset to Default, Reboot, and Miscellaneous. Each option has a brief description of its function.

WiFi Combo Broadband Gateway (R0.02)

ADMINISTRATOR's MAIN MENU Status Wizard Advanced Logout

BASIC SETTING FORWARDING RULES SECURITY SETTING ADVANCED SETTING **TOOLBOX**

• System Info

• Firmware Upgrade

• Backup Setting

• Reset to Default

• Reboot

• Miscellaneous

Toolbox

- **View Log**
 - View the system logs.
- **Firmware Upgrade**
 - Prompt the administrator for a file and upgrade it to this device.
- **Backup Setting**
 - Save the settings of this device to a file.
- **Reset to Default**
 - Reset the settings of this device to the default values.
- **Reboot**
 - Reboot this device.
- **Miscellaneous**
 - MAC Address for Wake-on-LAN: Let you to power up another network device remotely.
 - Domain Name or IP address for Ping Test: Allow you to configure an IP, and ping the device. You can ping a specific IP to test whether it is alive.

3.2.5.1 System Info

WiFi Combo Broadband Gateway (R0.02)

ADMINISTRATOR's MAIN MENU Status Wizard Advanced Logout

BASIC SETTING FORWARDING RULES SECURITY SETTING ADVANCED SETTING TOOLBOX

- System Info
- Firmware Upgrade
- Backup Setting
- Reset to Default
- Reboot
- Miscellaneous

System Information

Item	Setting
▶ WAN Type	Dynamic IP Address
▶ Display time	Sat, 01 Jan 2000 08:25:01 +0800

System Log

Time	Log
Jan 1 08:00:02	kernel: klogd started; BusyBox v1.3.2 (2009-07-06 11:15:48 CST)
Jan 1 08:00:03	commander: CSID0001000F read err -61
Jan 1 08:00:04	commander: wlan_num=1
Jan 1 08:00:04	commander: num_wlan_pre=1
Jan 1 08:00:09	udhcpd[1400]: udhcpd (v0.9.9-pre) started
Jan 1 08:00:09	udhcpd[1400]: Unable to open /var/run/udhcpd.leases for reading
Jan 1 08:00:09	commander: handle_spap: spap_enable = 0
Jan 1 08:00:09	commander: handle_ddns: ddns_enable = 0
Jan 1 08:00:09	commander: handle_rbydom: rbydom_enable = 0
Jan 1 08:00:09	commander: handle_rbyip: rbyip_enable = 0
Jan 1 08:00:09	httpd: CSID80020101 read err -61
Jan 1 08:00:09	init: Starting pid 1436, console /dev/ttyS1: '/bin/ash'
Jan 1 08:00:09	syslog: CSID80004231 read err -61
Jan 1 08:00:09	syslog: CSID80004232 read err -61
Jan 1 08:00:09	syslog: CSID80004233 read err -61


Page: 1/51 (Log Number: 760)

You can view the System Information and System log.
And download/clear the System log in this page.

註解 [032]: 刪除逗號

3.2.5.2 Firmware Upgrade

You can upgrade firmware by clicking “Upgrade” button.



3.2.5.3 Backup Setting

You can backup your settings by clicking the “Backup Setting” button and save it as a bin file.

Once you want to restore these settings, please reference the **Section 3.2.5.2 Firmware Upgrade**.

註解 [033]: 應改為 refer to

3.2.5.4 Reset to Default

You can also reset this product to factory default by clicking the **Reset to default** button.

3.2.5.5 Reboot

You can also reboot this product by clicking the **Reboot** button.

3.2.5.6 Miscellaneous

Item	Setting
▶ MAC Address for Wake-on-LAN	<input type="text"/> <input type="button" value="Wake up"/>
▶ Domain Name or IP address for Ping Test	<input type="text"/> <input type="button" value="Ping"/>

1. MAC Address for Wake-on-LAN

Wake-on-LAN is a technology that enables you to power up a networked device remotely. In order to enjoy this feature, the target device must be Wake-on-LAN enabled and you have to know the MAC address of this device, say 00-11-22-33-44-55. Clicking "Wake up" button will make the gateway to send the wake-up frame to the target device immediately.

註解 [034]: 應改爲 saying

2. Domain Name or IP address for Ping Test

You can key in URL or IP address, and then click the "Ping" button for test.

Troubleshooting

This section provides an overview of common issues, and possible solutions for the installation and operation of the WiFi Combo Broadband Gateway.

1. Unable to access the Configuration Menu when I use my computer to configure the gateway. Why?

Note: It is recommended that you use an Ethernet connection to configure the

註解 [035]: 沒有句點

Ensure that the **Ethernet LED** on the WiFi Combo Broadband Gateway is **ON**.

If the **LED** is **NOT ON**, check to see if the cable for the Ethernet connection is securely inserted.

Note: Ensure that the **IP Address** is in the same range and subnet as the WiFi Combo Broadband Gateway. The IP Address of the WiFi Combo Broadband Gateway is 192.168.123.254. All the computers on the network must have a unique IP Address within the same range (e.g., 192.168.123.x). Any computers that have identical IP Addresses will not be visible on the network. All computers must also have the same subnet mask (e.g., 255.255.255.0).

Do a **Ping test** to make sure that the WiFi Combo Broadband Gateway is responding.

Go to **Start > Run**.

- 1: Type **cmd**.
- 2: Press **Enter**.
- 3: Type "**ping 192.168.123.254**". A successful ping shows four replies.

Note: If you have changed the **default IP Address**, ensure you ping the correct IP Address assigned to the WiFi Combo Broadband Gateway.

Ensure that your Ethernet Adapter is working properly, and that all network drivers are installed properly.

Note: Network adapter names will vary depending on your specific adapter. The installation steps listed below are applicable for all network adapters.

1. Go to **Start > My Computer > Properties**.
2. **Select the Hardware Tab**.
3. Click **Device Manager**.
4. Double-click on "**Network Adapters**".
5. Right-click on **Wireless Card bus Adapter**, or **your specific network adapter**.
6. Select **Properties** to ensure that all drivers are installed properly.
7. Look under **Device Status** to see if the device is working properly.
8. Click "**OK**".

2: Why my wireless client can NOT access the Internet?

Note: Establish WiFi Connection. As long as you select either **WEP** or **WPA-PSK** encryption, ensure encryption settings match your WiFi settings. Please refer to your WiFi adapter documentation for additional information.

Ensure that the wireless client is associated and joined with the correct Access Point.

To check this connection, follow the steps below:

1. **Right-click** on the **Local Area Connection icon** in the taskbar.
2. Select **View Available Wireless Networks in Wireless Configure**. The **Connect to Wireless Network** screen appears. Ensure you have selected the correct available network.

Ensure the IP Address assigned to the wireless adapter is within the same subnet as the Access Point and gateway. The WiFi Combo Broadband Gateway has an IP Address of **192.168.123.254**. Wireless adapters must have an IP Address in the same range (e.g., 192.168.123.x). Although the subnet mask must be the same for all the computers on the network, no two devices may have the same IP Address. Therefore, each device must have a unique IP Address.

To check the **IP Address** assigned to the wireless adapter, follow the steps below:

1. Enter ipconfig /all in command mode
2. Enter ping 192.168.123.254 to check if you can access the WiFi Combo Broadband Gateway.

3. Why does my wireless connection keep dropping?

You may try following steps to solve.

- Antenna Orientation.
 - 1: Try different antenna orientations for the WiFi Combo Broadband Gateway.
 - 2: Try to keep the antenna at least 6 inches away from the wall or other objects.
- Try changing the channel on the WiFi Combo Broadband Gateway, and your Access Point and Wireless adapter to a different channel to avoid interference.
- Keep your product away (at least 3-6 feet) from electrical devices that generate RF noise, like microwaves, monitors, electric motors, etc.

4. Why I am unable to achieve a wireless connection?

Note: An Ethernet connection is required to troubleshoot the WiFi Combo Broadband Gateway.

If you have enabled Encryption on the WiFi Combo Broadband Gateway, you must also enable encryption on all wireless clients in order to establish a wireless connection.

- For 802.11g, the encryption settings are: 64 or 128 bit. Ensure that the encryption bit level is the same for both the WiFi Combo Broadband Gateway, and your Wireless Client.
- Ensure that the SSID (Service Set Identifier) on the WiFi Combo Broadband Gateway and the Wireless Client are exactly the same.
If they are not, your wireless connection will not be established.
- Move the WiFi Combo Broadband Gateway and the wireless client into the same room, and then test the wireless connection.
- Disable all security settings such as **WEP**, and **MAC Address Control**.
- Turn off the WiFi Combo Broadband Gateway and the client.
Turn the WiFi Combo Broadband Gateway back on again, and then turn on the client.
- Ensure that all devices are set to **Infrastructure** mode.
- Ensure that the LED indicators are indicating normal activity. If not, ensure that the AC power and Ethernet cables are firmly connected.
- Ensure that the IP Address, subnet mask, gateway and DNS settings are correctly entered for the network.
- If you are using 2.4GHz cordless phones, X-10 equipment, or other home security systems, ceiling fans, or lights, your wireless connection may degrade dramatically, or drop altogether.

To avoid interference, change the Channel on the WiFi Combo Broadband Gateway, and all devices in your network.

- Keep your product at least 3-6 feet away from electrical devices that generate RF noise.

註解 [036]: 應改爲 am I

Examples include: microwaves, monitors, electric motors, and so forth.

5. I just do not remember my encryption key. What should I do?

- If you forgot your encryption key, the WiFi card will be unable to establish a proper connection.

If an encryption key setting has been set for the WiFi Combo Broadband Gateway, it must **also** be set for the WiFi card that will connect to the WiFi Combo Broadband Gateway.

註解 [037]: 應在 be 動詞後面

To reset the encryption key(s), login to the WiFi Combo Broadband Gateway using a wired connection. (Please refer to “Basic > Wireless (Security–No Encryption)” on page 10, for additional information).

7. How do I reset my WiFi Combo Broadband Gateway to its factory default settings?

If other troubleshooting methods have failed, you may choose to **Reset** the WiFi Combo Broadband Gateway to its factory default settings.

To hard-reset the WiFi Combo Broadband Gateway its factory **default** settings, follow the steps listed below:

1. Ensure the WiFi Combo Broadband Gateway is powered on
2. Locate the **Reset** button on the back of the WiFi Combo Broadband Gateway.
3. Use a paper clip to press the **Reset** button.
4. Hold for 10 seconds and then release.
5. After the WiFi Combo Broadband Gateway reboots, it is reset to the factory **default** settings.

Note: Please note that this process will take a few minutes.

8. What is VPN?

- VPN stands for “Virtual Private Networking.” VPNs create a “tunnel” through an existing Internet connection using PPTP (Point-to-Point Tunneling Protocol) or IPSec (IP Security) protocols with various encryption schemes including Microsoft Challenge Handshake Authentication Protocol (MS-CHAP).
- This feature allows you to use your existing Internet connection to connect to a remote site with added security. If your VPN connection is not functional, verify that your VPN dial-up configuration is correct.

Note: This information should be provided to you from your VPN provider.

Pressing the Reset Button restores to its original factory **default** settings.

9. What can I do if my Ethernet cable does not work properly?

- First, ensure that there is a solid cable connection between the Ethernet port on the gateway, and your NIC (Network Interface Card).
- Second, ensure that the settings on your NIC adapter are “Enabled,” and set to accept an IP address from the DHCP.
- If settings appear to be correct, ensure that you are *not* using a crossover Ethernet cable.

Although the WiFi Combo Broadband Gateway is MDI/MDIX compatible, not all NICs are.

Therefore, it is recommended that you use a patch cable when possible.

4. Technical Specifications

3G Access	USB port
Standards	IEEE 802.11b/g IEEE 802.3 IEEE 802.3u
Wireless	
Standard	IEEE 802.11 B\G\N
Data Rate	11B: 11, 5.5, 2, 1 Mbps 11G: 54, 48, 36, 24, 18, 12, 9, and 6 Mbps 11N: Max physical rate up to 150Mbps
Frequency	2.4 – 2.462 GHz, CCK / OFDM modulation
Range Coverage	Indoors approx. 30-50 meters; Outdoors up to 80-100 meters
# of Channels	1-11 for N. America (FCC);1-11 for Canada (DOC) 1-13 Europe (Except Spain and France) (ETSI) 1-14 Japan (TELEC);
Security	64-bit and 128-bit WEP Encryption; WPA encryption
Antenna	PIFA Antenna.
Firewall	IP Filtering NAT (Network Address Translation) with VPN Pass through MAC Filtering
Supported WAN type	3G,Static IP, Dynamic IP, PPPoE,PPTP,L2TP
Connection Scheme	Connect-on-demand, Auto-Disconnect
NAT function	Class C ;One-to-Many; Max 253 Users; Virtual Server; DMZ Host
VPN	PPTP, L2TP and IPSec Pass Through
Config.& Management	Web-Based IE, Navigator browser and SNMP
IP assignment	DHCP Server and Client
Working Environment	Temperature: 0~40°C, Humidity 10%~90% non-condensing
OS supported	Windows 95/98/ME/NT/2000/XP; Linux
Power	Full range(100-240V), Switching 5V 2.0A

FCC statement in User's Manual (for class B)

"Federal Communications Commission (FCC) Statement

This Equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

1. The device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.

2. This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

3. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.