3 Connect to your network

To use your player, you must connect it to your home network. Typically, customers connect to a wireless (or wired) router rather than directly to a broadband modem. Choose Wireless or Wired setup below, then follow the Guided Setup on-screen to complete the connection proces IMPORTANT: Don't place anything on top of your Roku player. Placing objects on top of your player may interfere with the wireless signal, or cause the player to overheat.

Wireless

Place your player within range of your wireless network. Avoid enclosing your player in a cabinet. During Guided Setup, you may need to enter a password if your network has security turned on.

Router or

Wired

Use an Ethernet cable (not included) to connect your player to your router.



📕 📕 📕 СМҮК 4c/4c

Complete Guided Setup 4

On your TV

· Use the remote to follow the on-screen instructions. Your player may download software updates or restart during setup.

 When Guided Setup prompts you to enter your Roku linking code, use your computer to go to roku.com/link. Enter the code that appears on your TV screen and then create a Roku account, if you do not already have one.

 Once you complete setup, select a channel icon (such as Netflix or Amazon Video On Demand) to view, or visit the Roku Channel Store to add more channels (such as the Pandora Internet radio channel)

· Some Roku channels may require you to activate your Roku player to access their content. Just follow the on-screen instructions when you launch a channel for the



Industry Canada Statement This device complies with RSS-210 of the Industry Canada Rules. Operation is subject to the following two

conditions: 1) this device may not cause interference and 2) this device must accept any interference, including interference that may cause undesired operation of the

device MPORTANTNOTE: IC Radiation Exposure Statement: This equipment complex with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

5 Basic remote functions

To do this	Press this
Move left or right	S or D
Move up or down	🛆 or 💟
Scroll left one page at a time	
Scroll right one page at a time	0
Select an option from a menu	OK
Return to previous screen	(from top of screen)
Return to Roku home screen	<u>۵</u>
Start or pause playback	•
Exit playback	
Fast forward	0
Rewind	•

Need help?

To view frequently asked questions, watch instructional videos, access user To view frequently asked questions, watch instructional videos, access u forums, or to contact Roku customer support, go to roku.com/support.

Forums, or to contact kokk customer support, go to rokk.com/support. The deciment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the provide the support of the support of

- Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undered operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IEEE 802.11b or 802.11g operation of this product in the U.S.A. is firmware-limited to channels 1 through 11.

IMPORTANT NOTE:

PCC Reliation Exposure Statement: This equipment complex with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 32cm between the radiator & your body. This transmitter must not be oc-located or operating in onjunction with any other antenna or transmitter.

Get started ① Plug in ② Connect ③ Watch

Roku

60000000000000000000000000000000000000

6 3 8 5 9 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6
요즘 같은 사람들이 많은 것은 것을 가지 않는 것을 다 가지 않는 것을 다 가지 않는 것을 했다.
000000000000000000000000000000000000000
