

# N150 Wireless ADSL 2/2+ Modem Router TEW-718BRM5

**Quick Installation Guide** 

## 1. Before You Start

# **Package Contents**


- TEW-718BRM5
- Multi-Language Quick Installation Guide
- CD-ROM (User's Guide)
- Power adapter (5V DC, 1.2A)
- Detachable antenna
- Network cable (1.5 m / 5 ft.)
- RJ-11 telephone cable (1.8 m / 5.4 ft)

## **Installation Requirements**

- · A computer with a wired or wireless network adapter and Web browser
- · Broadband Internet

## 2. Installation


- 1. Connect the detachable antenna to the TFW-718BRM5.
- Connect one end of the RJ-11 telephone cable to the TEW-718BRM5's ADSL port. Connect the other end of the cable to the phone jack.
- 3. Connect your computer to one of the TEW-718BRM5's LAN ports
- 4. Connect the power adapter to the TEW-718BRM5 and then to a power outlet.



5. Verify that the status LED indicators on the front of the modem to confirm that the device is fully functional: Status (Green), ADSL (Green), WLAN (Green) and the LAN port (1, 2, 3, 4) your computer is connected.(Green).

**Note:** It is recommended that you configure the TEW-718BRM5 from a wired computer.

**6.** Open your web browser, type **http://192.168.10.1** in the Address bar, and then press **Enter**.



7. Enter the User name and Password, and then click **OK**. By default:

User Name: admin
Password: admin

Note: User name and Password are case sensitive.

The Setup Wizard will automatically appear. Click Setup Wizard if the Setup Wizard does not automatically appear.



9. Follow the setup wizard instructions and then click Finish.

### Note:

- To protect your network from any unauthorized access it is recommended to enable wireless encryption. Please refer to the User Guide's Guide on the CD-ROM for information on setting up encryption on the modem router.
- Once encryption is enabled on the modem router, make sure your encryption key is kept in a safe location. Each additional wireless computer/device will require you to input the encryption key.
- Open up your browser and enter in a URL (e.g. www.trendnet.com) to verify that you have Internet connection.

## Wireless modem router installation is now complete.

For detailed information regarding the **TEW-718BRM5's** configuration and advanced settings, please refer to the User's Guide CD-ROM, or TRENDnet's website at http://www.trendnet.com.

GPL/LGPL General Information

This TRENDnet product includes free software written by third party developers. These codes are subject to the GNU General Public License ("GPL") or GNU Lesser General Public License ("LGPL"). These codes are distributed WITHOUT WARRANTY and are subject to the copyrights of the developers. TRENDnet does not provide technical support for these codes. The details of the GNU GPL and LGPL are included in the product CD-ROM.

Please also go to (http://www.gnu.org/licenses/gpl.txt) or (http://www.gnu.org/licenses/lapl.txt) for specific terms of each license.

The source codes are available for download from TRENDnet's web site (http://trendnet.com/downloads/list\_qpl.asp) for at least three years from the product shipping date.

You could also request the source codes by contacting TRENDnet. 20675 Manhattan Place, Torrance, CA 90501, USA, Tel: +1-310-961-5500 Fax: +1-310-961-5511

#### Certifications


This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received. Including interference that may cause undesired operation.









#### Note

The Manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

#### Advertencia

En todos nuestros equipos se mencionan claramente las características del adaptador de alimentacón necesario para su funcionamiento. El uso de un adaptador distinto al mencionado puede producir daños físicos vío daños al equipo conectado. El adaptador de alimentación debe operar con voltaje y frecuencia de la energia electrica domiciliaria exitente en el país o zona de instalación.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



## Product Warranty Registration

Please take a moment to register your product online. Go to TRENDnet's website at http://www.trendnet.com/register

**TRENDnet** 20675 Manhattan Place, Torrance, CA 90501, USA

Copyright @2013. All Rights Reserved. TRENDnet.

