ESR9850 Wireless 11N Gigabit AP Router
Quick Start Guide

Prerequisites:

- A standard CD-ROM drive
- ADSL / Cable Modem with RJ45 port.
- PC or Notebook with Ethernet network interface.
- Standard Web Browser
- CAT 5 network cable(s), RJ45 port on PC/Notebook.

STEP 1

Power up **ESR9850**. Please wait until WLAN starts blinking.

STEP 2

Insert **Wizard CD** into your CD-ROM drive.

The Wizard should start in a few seconds. If Wizard does not start

automatically, please browse the CD and Click on "**index.html**" to

activate SMART WIZARD**.**

EnGenius

ESR9850
Wireless N Gigabit Router

Smart Wizard

Quick Setup

User Manual

Adobe Reader

Exit

Please click on [**Quick Setup**] and follow the instructions given to complete the device initiation configuration.

Thank you for choosing **EnGenius**.