Support

Thank you for purchasing this NETGEAR product.

After installing your device, locate the serial number on the label of your product and use it to register your product at *https://my.netgear.com*.

You must register your product before you can use NETGEAR telephone support. NETGEAR recommends registering your product through the NETGEAR website.

For product updates and web support, visit *http://support.netgear.com*.

NETGEAR recommends that you use only the official NETGEAR support resources.

You can get the user manual online at *http://downloadcenter.netgear.com* or through a link in the product's user interface.

Trademarks

O NETGEAR, Inc., NETGEAR and the NETGEAR Logo are trademarks of NETGEAR, Inc. Any non-NETGEAR trademarks are used for reference purposes only.

Compliance

For the current EU Declaration of Conformity, visit http://support.netgear.com/app/answers/detail/a_id/11621/.

For regulatory compliance information, visit: http://www.netgear.com/about/regulatory/.

See the regulatory compliance document before connecting the power supply.

Quick Start

Nighthawk AC1900 WiFi Cable Modem Router Model C7000v2



Package Contents

The box contains the following items.





NETGEAR, Inc. 350 East Plumeria Drive San Jose, CA 95134, USA

NETGEAR[®]

Modem router

1. Connect a coaxial cable.

Use a coaxial cable that is provided by your cable company to connect the cable port on the modem router to a cable wall outlet or a line splitter.

Note: For Xfinity cable Internet service, Comcast Xfinity recommends connecting your modem router to a cable wall outlet.



2. Connect the power adapter.

Connect the power adapter to the modem router and plug the power adapter into an electrical outlet.

Wait for the Power LED ⁽¹⁾ and the Internet LED (1) to light solid green.

3. Connect a computer or WiFi device to the modem router.

To connect with WiFi, use the WiFi network name and password on the product label.

For a wired connection, use an Ethernet cable to connect a computer to an Ethernet port on the modem router.



4. Log in to the modem router. Launch a web browser.

The modem router menu displays.

If you do not see the modem router menu, enter **http://routerlogin.net** or **http://192.168.0.1** in the address field of the web browser.

When prompted, enter **admin** for the user name and **password** for the password.

5. Set up your Internet service.

For information about how to set up your Internet service, see "Set Up Your Internet Service" on page 6.

Contents

LEDs	2
Install Your Modem Router	4
Set Up Your Internet Service	6
WiFi Network Name and Password	8
Join the WiFi Network	9
View or Change the Modem Router Settings	10
Share a USB Drive on the Network	11
Share a USB Printer	13
NETGEAR genie App	14

LEDs

The LEDs on the modem router light to indicate modem router activity:



LED	Description
Power	 Solid green. Power is supplied to the modem router. Off. No power is supplied to the modem router. Solid red. Thermal cutoff mode. Power off the unit, let it cool, and move it away from heat sources (such as a TV, DVD player, or speakers) and keep it vertical in open air.
Downstream	 Solid amber. One downstream channel is locked. Solid green. Two or more downstream channels are locked. Blinking green. The modem router is scanning for a downstream channel. Off. No downstream channel is locked.
Upstream	 Solid amber. One upstream channel is locked. Solid green. Two or more upstream channels are locked. Blinking green. The modem router is scanning for an upstream channel. Off. No upstream channel is locked.
Internet	 Solid green. The modem router is online. Blinking green. The modem router is synchronizing with the cable provider's cable modem termination system (CMTS). Slow blinking amber and green. The modem router reached the traffic meter limit. (For information about the traffic meter, see the modem router's user manual.) Off. The modem router is offline.
2.4 GHz WiFi	 Solid green. The 2.4 GHz radio is on. Off. The 2.4 GHz radio is off.
5 GHz WiFi	 Solid green. The 5 GHz radio is on. Off. The 5 GHz radio is off.
Ethernet	 Solid green. A device is connected to an Ethernet port and powered on. Ethernet port LEDs for each port are located on the rear panel. Off. No device is connected to an Ethernet port.

LED	Description
WiFi On/Off button with LED	Pressing this button for two seconds turns the WiFi radios in the modem router on and off. If this LED is lit, the WiFi radios are on. If this LED is off, the WiFi radios are turned off and you cannot use WiFi to connect to the modem router.
WPS button with LED	This button lets you use WPS to join the WiFi network without typing the WiFi password. The WPS LED blinks during this process and then lights solid.

Install Your Modem Router

> To install your modem router:

1. Connect a coaxial cable.

Use a coaxial cable that is provided by your cable company to connect the cable port on the modem router to a cable wall outlet or a line splitter.

Note: For Xfinity cable Internet service, Comcast Xfinity recommends connecting your modem router to a cable wall outlet.

2. Connect the power adapter to the modem router and plug the power adapter into an electrical outlet.



Wait for the Power LED 🕲 and the Internet LED 🚳 to light solid green.

3. Connect a computer or WiFi device to the modem router.



To connect with WiFi, use the WiFi network name and password on the product label.

For a wired connection, use an Ethernet cable to connect a computer to an Ethernet port on the modem router.

4. Launch a web browser and log in to the modem router. The modem router menu displays.

If you do not see the modem router menu, enter **http://routerlogin.net** or **http://192.168.0.1** in the address field of the web browser.

When prompted, enter **admin** for the user name and **password** for the password.

5. Set up your Internet service.

For more information, see "Set Up Your Internet Service" on page 6.

Set Up Your Internet Service

Set up Internet service by using Comcast Xfinity's self-activation process. If you are unable to self-activate your modem router, call Comcast Xfinity customer service. After you complete the setup, perform a speed test.

Use the Self-Activation Process to Set Up Your Internet Connection

Before you start the self-activation process, make sure that your account number, account phone number, and login information (your email address or user name and password) are nearby.

To set up your Internet connection with Comcast Xfinity's self-activation process:

- 1. Close all web browsers.
- 2. Launch a web browser.

You are redirected to the Xfinity self-activation page. If you are not redirected to the Xfinity self-activation page, visit *www.comcast.com/activate*.

3. Provide your Xfinity credentials and complete the selfactivation process.

This process might take up to 15 minutes, during which the modem router reboots a couple of times.

Call Comcast Xfinity to Set Up Your Internet Connection

If you are unable to self-activate your modem router, call Comcast Xfinity customer service.

Before you call Comcast Xfinity, make sure that your account number, account phone number, email address, and password are nearby. The modem router's model number is C7000v2. The serial number and MAC address are on the product label.



To set up your Internet connection by calling Comcast Xfinity:

- 1. Call Comcast Xfinity customer service at 1-800-XFINITY (1-800-934-6489).
- 2. When asked, provide your account information and provide the modem router's model number and MAC address.
- 3. Wait for the Comcast Xfinity representative to confirm that your modem router is active.
- 4. If you do not get an Internet connection with the modem router, ask the Comcast Xfinity representative to look for your modem router online, and do one of the following depending on what the Comcast Xfinity representative tells you about your modem router:
 - If the modem router is not visible, the Comcast Xfinity representative can give you instructions to verify why the modem router does not connect with your high-speed Internet service.
 - If the modem router is visible to the Comcast Xfinity representative, reboot the modem router. Check your online status again.

WiFi Network Name and Password

The preset WiFi network name (SSID) and password (network key) are unique to your modem router, like a serial number. Because the modem router automatically uses WiFi security, you don't need to set it up. The WiFi settings are on the product label.



NETGEAR recommends that you use the preset WiFi settings because you can check the product label if you forget them. NETGEAR genie lets you change these settings. If you do so, write down the new WiFi settings and store them in a safe place.

You can write the WiFi settings from your product label in this space for easy reference.

WiFi network name (SSID):	
Network key (password):	

If you change the WiFi settings, write the new settings here for easy reference and store this booklet in a safe place.

WiFi network name (SSID):	
Network key (password):	

Join the WiFi Network

You can either use Wi-Fi Protected Setup (WPS) or select your WiFi network and type its password. For help with the **WPS** button on your computer or WiFi device, check the instructions or online help that came with that computer or device. Some older equipment cannot use WPS.

> To select your network and enter its password:

 Open the software utility that manages your WiFi connections on the computer or WiFi device that you want to connect to your modem router.

This utility scans for WiFi networks in your area.

- 2. Find and select your modem router's WiFi network name (SSID). The SSID is on the product label.
- 3. Enter the modem router's password (or your custom password if you changed it) and click the **Connect** button.

The password is on the product label.

4. Repeat Step 1 through Step 3 to add other computers or WiFi devices.

> To join the network using WPS:

1. Press the **WPS** button (S) on the modem router for 3–5 seconds.

The WPS LED on the modem router blinks green.

2. Within two minutes, on your computer or WiFi device, press its **WPS** button or click its onscreen **WPS** button.

The WPS LED on the modem router lights solid green when the computer or WiFi device connects to your modem router.

3. Repeat this process to add other computers or WiFi devices.

View or Change the Modem Router Settings

After you use genie to set up the modem router, you can log in to the modem router to view or change its settings.

Log In to the Modem Router

> To log in to the modem router:

- Connect a computer or WiFi device to the modem router. You can use an Ethernet cable or connect with WiFi:
 - For a wired connection, use an Ethernet cable to connect your computer to a yellow Ethernet port on your modem router.
 - To connect with WiFi, select and join your WiFi network.
- 2. Launch a web browser.
- 3. Enter **www.routerlogin.net** in the address field of the browser.

A login screen displays.

4. Enter **admin** for the user name and **password** for the password.

The BASIC Home screen displays.

Change the admin Password

> To change the admin password:

- 1. Launch a web browser.
- 2. Enter **www.routerlogin.net** in the address field of the browser.

A login screen displays.

3. Enter **admin** for the user name and **password** for the password.

The BASIC Home screen displays.

- 4. Select ADVANCED > Administration > Set Password.
- 5. Type your old password and type the new password twice.
- 6. Click the **Apply** button.

Your changes are saved.

Share a USB Drive on the Network

ReadySHARE lets you access and share a USB drive connected to the modem router USB port. (If your USB drive uses special drivers, it is not compatible.)



> To access the USB drive from a Windows computer:

1. Insert your USB storage drive into the USB port on the modem router.

If your USB drive uses a power supply, you must use it when you connect the USB drive to the modem router.

When you connect the USB drive to the modem router USB port, it might take up to two minutes before the modem router

is ready for sharing. By default, the USB drive is available to all computers on your local area network (LAN).

- 2. Select **Start > Run**.
- 3. Enter \\readyshare in the dialog box.
- 4. Click the **OK** button.
- > To access the USB drive from a Mac:
- 1. Insert your USB storage drive into the USB port on the modem router.

If your USB drive uses a power supply, you must use it when you connect the USB drive to the modem router.

When you connect the USB drive to the modem router USB port, it might take up to two minutes before it is ready for sharing. By default, the USB drive is available to all computers on your local area network (LAN).

- 2. Select Go > Connect to Server.
- 3. Enter **smb://readyshare** as the server address.
- 4. Click the **Connect** button.

Share a USB Printer

You can connect a USB printer to a USB port on the modem router and print wirelessly.

> To set up ReadySHARE Printer:

- 1. Connect the USB printer to a USB port on the modem router with a USB printer cable.
- 2. On each computer that will share the printer, do the following:
 - a. Install the current USB printer driver software (available from the printer manufacturer).
 - b. Download the NETGEAR USB Control Center utility from *www.netgear.com/readyshare* and install it.
 - c. Select the language.
- 3. If prompted, select the printer and click the **Connect** button for each computer.

When the first computer connects, the status changes to Manually connected by xxx.

For each computer, when you complete Step 3, the printer status displays as Available.

NETGEAR genie App

The free NETGEAR genie app lets you easily monitor, connect, and control your home network from a Windows or Mac computer, tablet, or smartphone. You can share and stream music or videos, diagnose and repair network issues, set up parental controls, and more:

- Access your modem router and change its settings or diagnose and repair network issues.
- Make a printer AirPrint compatible so that you can print from an iPad or iPhone.
- Use MyMedia to find and play media files in your network.
- Use Turbo Transfer to quickly send files from your computer or smartphone to another device on the network.
- Set up parental controls.
- Connect your smartphones and tablets to your home WiFi by scanning the WiFi QR code from genie.

Download the free genie app from www.NETGEAR.com/genie.

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

For operation within 5.15 \sim 5.25GHz frequency range, it is restricted to indoor environment.

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 29cm between the radiator & your body.