



Super G™ Wireless Access Point

Model # AP431W

User's Manual

Ver. 1A

Table of Contents

1. Introduction.....	3
2. Getting Started	4
3. Gathering Information	7
4. Configuring Network Address.....	8
5. Using Web Configuration Utility.....	15
6. Connecting to the Access Point	21
7. Web Configuration Utility	22
7.1 Primary Setup.....	22
7.2 System.....	29
7.3 Operating Mode	31
7.4 Access Control.....	36
7.5 Advanced Wireless	38
7.6 Setting Status	40
7.7 Help.....	41
Industry Canada Statement	43
Technical Support.....	44

1. Introduction

Congratulations on your purchase of this Super G™ Wireless Access Point. The Access Point features five operating modes. The Access Point mode connects your wireless clients with the wired part of your network. The AP client mode acts as a wireless network adapter for your PC or game console. The AP Repeater mode extends the range of your access point/wireless router by repeating the signal to wireless clients that are beyond the broadcasting range of the access point/wireless router. This provides the wireless clients with greater flexibility and mobility. The WDS bridges the network clients from various physically separate LANs into one virtual LAN. Finally, the WDS with AP bridges separate LANs into a virtual LAN while allowing wireless clients to connect with the device.

The Access Point is compatible with existing 802.11b and 802.11g network devices so it will work with most existing wireless devices. If you have other Super G™ compatible wireless network device, you can also enable Super G™ on the Access Point for faster transfer rate.*

Instructions for installing and configuring this product can be found in this manual. Before you install and use this product, please read this manual carefully for proper operation of this product.

Package Contents

Before you begin the installation, please check the items of your package:


- Super G™ Wireless Access Point
- Power Adapter
- RJ-45 Network Cable
- Antenna
- Quick Installation Guide
- Manual CD

If any item contained is damaged or missing, please contact your local dealer immediately. Also, keep the box and packaging materials in case you need to ship the unit in the future.


2. Getting Started

Please refer to the following diagrams to determine which operating mode you should use for your network.


Access Point




AP Client




Repeater



WDS





If you want to use the AP431W as an Access Point with minimal configuration, just connect it to your existing router or switch with a Cat. 5 network cable and then power it on. The Access Point is ready to use with its default settings:

SSID: **default**

Channel: **6**


Encryptions: **disabled**

If you want to configure the Access Point's settings or set it to other operating modes, please follow the rest of this guide.

Step 1 Connect one end of a network cable to the **Network** port of the Access Point and connect the other end to one of the **LAN** ports of the router (*See the diagram below*).

Step 2 Power on the Access Point by connecting one end of the supplied power adapter to the power jack of the Access Point and connecting the other end to an electrical outlet.


Step 3 Verify that all three lights on the Access Point are lit. If not, verify that all the connections are secure and try again.



3. Gathering Information

Step 1 On the wired computer, go to **Start, Run**, type **command** (for Windows 95/98/ME) or **cmd** (for Windows 2000/XP) and click **OK**.

Step 2 Type **ipconfig** and press **Enter**. Your network settings will be displayed.



```
C:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.
C:\Documents and Settings\Administrator>ipconfig

Windows IP Configuration

Ethernet adapter Local Area Connection:

    Connection-specific DNS Suffix . :
    IP Address . . . . . : 192.168.1.100
    Subnet Mask . . . . . : 255.255.255.0
    Default Gateway . . . . . : 192.168.1.1

C:\Documents and Settings\Administrator>
```

Step 3 Write down the values for the **IP Address**, **Subnet Mask**, and **Default Gateway** on a piece of paper.

Step 4 If you want to set the AP431W to a mode other than an Access Point, write down the following values for your existing wireless router or AP:

1. **SSID (Network Name)**
2. **Channel Number**
3. **Wireless Security Settings**

The AP431W needs to use the same wireless settings in order for it to work properly. You may gather these information from the web configuration utility of your wireless router.

Step 5 Refer to the **IP Address** you've written down from **Step 3**.


If the first three numbers of your **IP Address** are **192.168.1**, then you do not need to configure your computer's IP Address. Please continue to **Section 5, Using Web Configuration Utility**.

If the first three numbers of your **IP Address** are not **192.168.1**, (Ex. **192.168.2**), then please refer to the next section for instructions on how to change the IP Address.


4. Configuring Network Address

This section describes how to change your computer's IP Address to access the Access Point's Web Configuration Utility and then to change the Access Point's IP Address to match your existing Network Address.


Step 1 Go to **Start > Settings > Control Panel > Network and Internet Connections**.




Step 2 Select **Network Connections**.



Step 3 Right-click on **Local Area Connection** and select **Properties**.




Step 4 Select **Internet Protocol (TCP/IP)** and click on **Properties**.




Step 5 Select **Use the following IP address** and enter the following:

IP Address: **192.168.1.101**
Subnet Mask **255.255.255.0**




Click **OK** when done.


Step 6 Click **Close**.



Step 7 Open your web browser (Internet Explorer or Netscape) and enter **192.168.1.250** in the Address Bar and press **Enter**.




Step 8 Enter **admin** for both the **User name** and **Password** and click **OK**.




Step 9 Refer to the Network Settings you've written down from the previous section and change the first three numbers of the IP Address to match your local network address.


For example: If your computer's **IP Address** is **192.168.2.100**, change the first three numbers to **192.168.2** as well but leave the last number **250** alone.




Step 10 Enter the **Subnet Mask** and **Gateway** fields with exactly the same values as you got from running **ipconfig**.




Step 11 Click **Apply** to save the changes.



Step 12 Return to **Internet Protocol (TCP/IP) Properties** and select **Obtain an IP address automatically** and **Obtain DNS server address automatically** and click **OK**.



Step 13 Click **Close**.



Step 14 At the Command Prompt, type **ipconfig /release** and press **Enter**. You should see all 0's as shown below.

```
C:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\Administrator>ipconfig /release

Windows IP Configuration

Ethernet adapter Local Area Connection:

    Connection-specific DNS Suffix  . : 
    IP Address . . . . . : 0.0.0.0
    Subnet Mask . . . . . : 0.0.0.0
    Default Gateway . . . . . : 

C:\Documents and Settings\Administrator>
```

Step 15 Type **ipconfig /renew** and press **Enter**. You should receive a valid IP address as shown below.

```
C:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\Administrator>ipconfig /renew

Windows IP Configuration

Ethernet adapter Local Area Connection:

    Connection-specific DNS Suffix  . : 
    IP Address . . . . . : 192.168.2.101
    Subnet Mask . . . . . : 255.255.255.0
    Default Gateway . . . . . : 192.168.2.1

C:\Documents and Settings\Administrator>
```

Step 16 Type **ping 192.168.2.250** and press **Enter**. You should receive four Reply from messages as shown below.

```
C:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\Administrator>ping 192.168.2.250

Pinging 192.168.2.250 with 32 bytes of data:

Reply from 192.168.2.250: bytes=32 time<1ms TTL=255
Reply from 192.168.2.250: bytes=32 time=35ms TTL=255
Reply from 192.168.2.250: bytes=32 time=1ms TTL=255
Reply from 192.168.2.250: bytes=32 time=58ms TTL=255


Ping statistics for 192.168.2.250:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 58ms, Average = 23ms

C:\Documents and Settings\Administrator>
```

5. Using Web Configuration Utility


You can use the Access Point's built-in Web Configuration Utility to configure the encryption settings and operating modes. This section describes how to configure the Access Point's wireless and security settings.

Step 1 Open your Web Browser (Internet Explorer or Netscape), enter the IP Address of the Access Point (default: **192.168.1.250**) in the Address Bar and press **Enter**.



Note: If you have changed the IP Address of the Access Point, as described in the previous section, enter its new IP Address instead of the default.

Step 2 Enter **admin** for both the **User name** and **Password** and click **OK**.



Step 3 At the Wireless section, enter the **SSID (Network Name)** of your wireless network and the **channel** number.

The screenshot shows the 'Wireless' configuration page. The 'Wireless' tab is selected and highlighted with a red box. The MAC Address is 00:17:9a:b7:29:2b. The Super G Mode is set to 'Disable'. The SSID field contains 'default' and is highlighted with a red box. The SSID Broadcast is set to 'Enable'. The Channel is set to '6' and is highlighted with a red box. There is an unchecked checkbox for 'Auto Channel Scan'.

Step 4 If you have enabled encryption for your wireless network, you'll need to configure the same security settings on the Access Point as well. Select **Authentication**.

The screenshot shows the 'Wireless' configuration page with the 'Authentication' dropdown menu open. The 'Open System' option is selected and highlighted with a red box. The other options in the menu are Shared Key, Open System/Shared Key, WPA-EAP, WPA-PSK, WPA2-EAP, WPA2-PSK, WPA-Auto-EAP, and WPA-Auto-PSK. The Encryption is set to 'Disable'. The Key Type is set to 'HEX'. The Valid Key is set to 'First'. The First Key field contains six dots. The Second Key, Third Key, and Fourth Key fields are empty. The Transmission Rates are set to 'Auto'. The 64 Bits dropdown is visible. The Firmware Version is AP431W.v100.r541.t579-51.

WEP

Step 5a Select the same WEP authentication as your wireless network from the drop-down menu.

- Open System and disabling encryption implies no encryption
- Open System and enabling encryption implies WEP open system mode
- Shared Key and enabling encryption implies WEP shared key mode
- Open System/Shared Key and enabling encryption implies WEP auto switch mode

Wireless MAC Address: 00:17:9a:b7:29:2b

Super G Mode:

SSID:

SSID Broadcast:

Channel: Auto Channel Scan

Transmission Rates:

Authentication:

Encryption: Disabled Enabled

Key Type:

Valid Key:

First Key:

Second Key:

Third Key:

Fourth Key:

Firmware Version: AP431W.v100.r541.t579-51

The screenshot shows a configuration page for a wireless network. The 'Authentication' dropdown menu is open, showing options: Open System, Shared Key, and Open System/Shared Key. The 'Open System' option is highlighted with a red box. The 'Encryption' section has 'Disabled' selected. The 'Key Type' is set to 'HEX' and the key length is '64 Bits'. The 'Valid Key' is set to 'First'. There are four key input fields, with the first one containing eight dots. The firmware version is AP431W.v100.r541.t579-51.

Step 5b Enable **Encryption**, select the same **Key Type** and **Key Size** (64-Bits / 128-Bits / 152 Bits) from the drop-down menus, as the WEP settings in your wireless network.

The screenshot shows the 'Wireless' settings page. The 'Encryption' section is highlighted with a red box, showing 'Encryption: Disable Enable'. Below it, 'Key Type: ' and 'Key Size:

Other settings visible include: MAC Address: 00:17:9a:b7:29:2b, Super G Mode: , SSID: , SSID Broadcast: , Channel: Auto Channel Scan, Transmission Rates: , Authentication: , Valid Key: , First Key: , Second Key: , Third Key: , Fourth Key:

Step 5c If your WEP wireless network uses the First Key, select First in the **Valid Key** pull-down menu. Enter the same **key (password)** of your wireless network in the **First Key** field and click **Apply**. Skip to **Step 8**.

The screenshot shows the 'Wireless' settings page. The 'Valid Key' and 'First Key' fields are highlighted with a red box. 'Valid Key' is set to 'First' and 'First Key' contains a password represented by dots. The 'Apply' button is also highlighted with a red box.

Other settings visible include: Firmware Version: AP431W.v100.r541.t579-51, Second Key: , Third Key: , Fourth Key:

WPA-EAP

Step 6 Select **WPA-EAP** from the drop-down menu and enter all the applicable fields. Click **Apply** and proceed to **Step 8**.

The screenshot shows a configuration interface for wireless settings. On the left, a blue sidebar contains the text "Wireless" and "Firmware Version: AP431W.v100.r541.t579-51". The main area contains various configuration fields:

- MAC Address: 00:17:9a:b7:29:2b
- Super G Mode:
- SSID:
- SSID Broadcast:
- Channel: Auto Channel Scan
- Transmission Rates:
- Authentication: (highlighted with a red box)
- Cipher Type: Group Key Update Interval:
- RADIUS Server:
- RADIUS Port:
- RADIUS Secret:

At the bottom, there are three buttons: "Apply" (highlighted with a red box), "Cancel", and "Help".

WPA-PSK


Step 7 Select **WPA-PSK** from the drop-down menu and enter all the applicable fields. Click **Apply** and proceed to **Step 8**.

The screenshot shows a configuration window titled "Wireless". On the left is a blue sidebar with the word "Wireless" in white. The main area contains the following settings:

- MAC Address: 00:17:9a:b7:29:2b
- Super G Mode:
- SSID:
- SSID Broadcast:
- Channel: Auto Channel Scan
- Transmission Rates:
- Authentication: (This field is highlighted with a red border)
- Cipher Type: Group Key Update Interval:
- PassPhrase:

At the bottom left, it says "Firmware Version: AP431W.v100.r541.t579-51". At the bottom center, there are three buttons: "Apply" (highlighted with a red border), "Cancel", and "Help".

Step 8 For best result, place the Access Point at a central location where it is accessible to all the wireless computers.



6. Connecting to the Access Point

Once you have properly configured the Access Point, your wireless computers should be able to detect its signal.

Use your wireless network adapter's utility to detect and connect to the Access Point. You can identify the Access Point by its **MAC Address**, which is displayed in the **BSSID** field of your wireless network adapter's utility.

You can check the Access Point's **MAC Address** on its bottom label.




If the signal is weak, try reorienting the Access Point's antenna or relocate the Access Point to a different place.

7. Web Configuration Utility

The Access Point comes with a built-in Web Configuration Utility that allows you to easily configure its various features. This section describes how to use the Web Configuration Utility.


7.1 Primary Setup

Step 1 Open your Web Browser (Internet Explorer or Netscape), enter the default IP Address of the Access Point **192.168.1.250** in the Address Bar and press **Enter**.



Note: If you have changed the IP Address of the Access Point, enter its new IP Address instead of the default.

Step 2 Enter **admin** for both the User name and Password fields and click **OK**.



The **Primary Setup** page is the main screen for configuring the Access Point. You can configure its IP Address and Wireless settings from this page.

AIRLINK 101 networkingsolutions **Primary Setup** **System** **Operating Mode** **Access Control** **Advanced Wireless** **Setting Status** **Help** **SUPER G Wireless Access Point**

Primary Setup This section contains the primary configuration for the Access Point. You should be able to customize easily the Ethernet and Wireless interface in this section. **Remember to press Apply for finalizing your configuration.**

LAN MAC Address: 00:17:9a:b7:29:2b

Configuration Type: Static (Manual) ▾

IP address: 192.168.1.250 This is the IP address, Subnet Mask and

Subnet Mask: 255.255.255.0 Default Gateway of the Access Point as it

Gateway: 192.168.1.1 is seen by your local network.

Country North USA ▾

Wireless MAC Address: 00:17:9a:b7:29:2b

Super G Mode: Disable ▾

SSID: default

SSID Broadcast: Enable ▾

Channel: 6 ▾ Auto Channel Scan

Transmission Rates: Auto ▾

Authentication: Open System ▾

Encryption: Disable Enable

Key Type: HEX ▾ Key Size: 64 Bits ▾

Valid Key: First ▾

First Key: ●●●●●●●●

Second Key: _____

Third Key: _____

Fourth Key: _____

Firmware Version: AP431W.v100.r541.t579-51

Apply Cancel Help

LAN

LAN	MAC Address: 00:17:9a:b7:29:2b
Configuration Type:	<input type="text" value="Static (Manual)"/>
IP address:	<input type="text" value="192.168.2.250"/> This is the IP address, Subnet Mask and
Subnet Mask:	<input type="text" value="255.255.255.0"/> Default Gateway of the Access Point as it
Gateway:	<input type="text" value="192.168.2.1"/> is seen by your local network.

MAC Address: Displays the Access Point's MAC Address.

Configuration Type: If you want the Access Point to obtain an IP address automatically from a DHCP server, then select **Dynamic (DHCP)**. If you will assign the Access Point a static IP address, then select **Static (Manual)** and enter an IP Address, Subnet Mask, and Default Gateway address in the corresponding fields.

Note: It is recommended that you assign a static IP Address for the Access Point so you can access its web configuration utility with ease.

Wireless

Wireless	MAC Address: 00:17:9a:b7:29:2b
Super G Mode	<input type="text" value="Disable"/>
SSID:	<input type="text" value="default"/>
SSID Broadcast:	<input type="text" value="Enable"/>
Channel:	<input type="text" value="6"/> <input type="checkbox"/> Auto Channel Scan
Transmission Rates:	<input type="text" value="Auto"/>
Authentication:	<input type="text" value="Open System"/>
Encryption:	<input checked="" type="radio"/> Disable <input type="radio"/> Enable
Key Type:	<input type="text" value="HEX"/> Key Size: <input type="text" value="64 Bits"/>
Valid Key:	<input type="text" value="First"/>
First Key:	<input type="text" value="••••••••"/>
Second Key:	<input type="text"/>
Third Key:	<input type="text"/>
Fourth Key:	<input type="text"/>

Super G Mode: Choose from **Disable**, **Super G™ without Turbo** or **Super G™ with Dynamic Turbo** as the wireless mode that your wireless network is using. **Disable** implies using **11b/11g**.

SSID: The SSID is the network name shared among all devices in a wireless network. It must be identical for all devices in the wireless network.

SSID Broadcast: To broadcast the Access Point's SSID, select **Enable**. When wireless clients survey the local area for wireless networks to associate with, they will pick up the SSID broadcast by the Access Point. If you do not want to broadcast the Access Point's SSID, then select **Disable**.

Channel: Select the appropriate channel (1 to 11) from the list provided to correspond with your network settings, All devices in your wireless network must use the same channel in order to function correctly. Enable **Auto Channel Scan** allows the Access Point to automatically scan for a clear channel.

Note: If you enable Auto Channel Scan, then you cannot specify a channel setting.

Transmission Rates: The default setting is **Auto**. The range is different according to the Wireless Mode you select.

You can select a range of transmission speeds, or you can keep the default setting- Auto to have the Access Point automatically uses the fastest possible data rate. Auto-Fallback will negotiate the best possible connection speed between the Access Point and a wireless client.


Authentication: Select the proper authentication for the encryption of your network.

Encryption: Choose **Enable** to select your security type, or the default setting **Disable** to connect with better performance. Disabling security setting will make your network more vulnerable to intrusion.

7.1.1 Wireless Encryption Settings

WEP

Wired Equivalent Privacy (WEP) is an encryption method used to protect your data during wireless communications. These settings must be identical to your existing wireless network's WEP settings. If your network supports WPA or WPA-PSK security, it is recommended that you use those encryptions for better security.



The screenshot shows a configuration interface for WEP. It includes a dropdown menu for 'Authentication' set to 'Shared Key', radio buttons for 'Encryption' with 'Enable' selected, a dropdown for 'Key Type' set to 'HEX', and a dropdown for 'Key Size' set to '64 Bits'. Below these are four key input fields: 'Valid Key' (set to 'First'), 'First Key' (filled with 10 dots), 'Second Key', 'Third Key', and 'Fourth Key'.

Authentication Type: Choose between **Open System** or **Shared Key**.

Encryption: Choose **Disable** or **Enable**.

Key Type: Choose **HEX** or **ASCII**

Key Size: Choose between **64-bit**, **128-bit** and **152-bit** encryption.

Valid Key: Select a key to be the active key.

Key 1 – 4: Manually assign a passphrase for each key.

- If you selected **HEX** and **64 bits** encryption, enter **10** HEX characters.
- If you selected **HEX** and **128 bits** encryption, enter **26** HEX characters.
- If you selected **HEX** and **152 bits** encryption, enter **32** HEX characters.
- If you selected **ASCII** and **64 bits** encryption, enter **5** ASCII characters.
- If you selected **ASCII** and **128 bits** encryption, enter **13** ASCII characters.
- If you selected **ASCII** and **152 bits** encryption, enter **16** ASCII characters.

Note: HEX number is a number from 0 to 9 and a letter from A to F. ASCII is any alphanumeric character.

Click **Apply** to save the changes.

WPA-EAP

If your network uses a RADIUS server for authentication, you may select WPA-EAP as your encryption setting.

Authentication: WPA-EAP

Cipher Type: AUTO Group Key Update Interval: 1800

RADIUS Server

RADIUS Port: 1812

RADIUS Secret

Firmware Version: AP431W.v100.r541.t579-51

Apply Cancel Help

Authentication Type: Choose between **WPA-EAP**.

Cipher Type: Select the WPA Algorithm (**AUTO**, **AES** or **TKIP**) that your network uses.

Group Key Update Interval: Enter the key renewal time in seconds. Default is 1800 seconds.

RADIUS Server: Enter the **IP Address** of your RADIUS server.


RADIUS Port: Enter the Authentication Port number of your RADIUS server.

RADIUS Secret: Enter the Shared Key for your RADUS server.

Click **Apply** to save the changes.

WPA-PSK

If your network supports WPA-PSK, it is recommended that you use this encryption setting for stronger security over WEP.



The screenshot shows a configuration interface for WPA-PSK. On the left, there is a blue vertical bar with the text "Firmware Version: AP431W.v100.r541.t579-51". To the right, there are several input fields: "Authentication:" with a dropdown menu set to "WPA-PSK", "Cipher Type:" with a dropdown menu set to "AUTO", "Group Key Update Interval:" with a text input field containing "1800", and "PassPhrase:" with an empty text input field. At the bottom, there are three buttons: "Apply", "Cancel", and "Help". The "Apply" button is highlighted with a red border.

Authentication Type: Choose between **WPA-PSK**.

Cipher Type: Select the WPA Algorithm (**AUTO**, **AES** or **TKIP**) that your network uses.

Group Key Update Interval: Enter the desired key renewal time in seconds. Default is 1800 seconds.

PassPhrase: Enter a password for your wireless network. The key should be 8 ~ 63 characters in alphanumeric.

Note that these settings must be exactly the same as your access point/wireless router.

Click **Apply** to save the changes.

7.2 System

The System page allows you to change the Access Point's login password as well as other administrative functions.

System

This section contains the It is strongly recommended to change the default password for your Access Point in order to avoid any security risks. In this section you can also upgrade the firmware.

AP Password: (Enter New Password)
 (Re-enter to Confirm)

Restore Factory Defaults: YES NO

Note: If YES, all setting will be restored as factory defaults

Backup/Restore Setting:

Note: Click on "Backup Setting" to create and save the setting on your local hard drive.
Click on "Restore Setting" to load the setting profile from your hard drive.

Firmware Upgrade: Current Version: AP431W.v100.r541.t579-51

AP Password: Enter the new login password and re-enter to confirm the new password. This is the password used for logging into the Access Point's Web Configuration Utility.


Restore Factory Defaults: Select **Yes** and click **Apply** to reset all of the settings to factory default.

Backup/Restore Setting: Click on the **Backup Setting** button to save your settings as a file in your PC. Later when you want to restore the settings, just **Browse** for the previously saved file and click on the **Restore Setting** button.

Firmware Upgrade: Click on the Firmware Upgrade button to update the firmware. You can download the updated firmware from our web site at www.airlink101.com

Step 1 Unzip the new firmware.

Step 2 Click on **Browse** to locate the new firmware and click on **Firmware Upgrade** to change the AP firmware.




The screenshot shows a web interface for a firmware upgrade. On the left, there is a blue gradient header with the text "Firmware Upgrade:". To the right of this header, the text "Current Version: AP431W.v100.r541.t579-51" is displayed. Below the header and version information, there is a horizontal input field. To the right of this field are two buttons: "Browse..." and "Firmware Upgrade". Both buttons are highlighted with a red rectangular border.


Warning: Upgrading firmware may take a few minutes, please don't turn off the power or press the reset button.

7.3 Operating Mode

The Operating Mode page allows you to select different functions according to your needs.



Access Point: This mode allows your wireless computers to connect to your wired network. (Default mode)




AP Client

The AP Client mode converts the Access Point to a wireless network adapter, allowing the network device such as your computer or game console to become a wireless client.

Step 1 Select **AP Client** and enter the MAC address of the remote AP or click on the **Scan** button for any available wireless network.

Step 2 Select the desired wireless network from the list.

Step 3 Click **Apply** to save the changes.



Operating Mode In this section you can change the operating mode of the 802.11g AP.

Operating Mode

Remote AP MAC Address

SSID

Type	CH	Signal	BSSID	Security	SSID
<input type="checkbox"/> AP BSS	10	100%	00:0d:72:13:68:e1	WEP	2WIRE217
<input type="checkbox"/> AP BSS	11	100%	00:09:5b:dd:f0:b6	WPA-PSK	TemporarilyDown

Step 4 Once the Access Point has restarted, you may disconnect it from the wireless router and connect it to the Ethernet port of your computer or game console.



AP Repeater

The AP Repeater mode converts the Access Point to a wireless repeater. By extending the wireless signal of the source AP/wireless router, the wireless coverage is expanded.

Step 1 Select **AP Repeater** and enter the MAC address or use the **Scan** button to search for the remote AP (source AP/wireless router). Click **Apply** to save the changes.



Operating Mode In this section you can change the operating mode of the 802.11g AP.


Operating Mode

Remote AP MAC Address

SSID

Type	CH	Signal	BSSID	Security	SSID	
<input type="checkbox"/>	AP BSS	10	100%	00:0d:72:f3:68:e1	WEP	2WIRE217
<input type="checkbox"/>	AP BSS	11	100%	00:09:5b:dd:f0:b6	WPA-PSK	TemporarilyDown

Step 2 Once the Repeater has restarted, you may disconnect it from the wireless router. For best result, place the Repeater at a central location between the wireless router and your wireless computers.




Note: The repeater mode may not be compatible with all routers due to the lack of a standard protocol for repeater mode.

WDS


The WDS mode converts the Access Point to a wireless bridge. It bridges the network clients from physically separate LANs into one virtual LAN.

Step 1 Select **WDS** and enter the MAC address of the remote APs. Click **Apply** to save the changes.



The screenshot shows the configuration interface for the AIRLINK 101 network solutions. The top navigation bar includes tabs for Primary Setup, System, Operating Mode, Access Control, Advanced Wireless, Setting Status, and Help. The 'Operating Mode' section is active, displaying the text: 'In this section you can change the operating mode of the 802.11g AP.' Below this, the 'Operating Mode' dropdown menu is set to 'WDS'. A section for 'Remote AP MAC Address' contains eight input fields, numbered 1 through 8, arranged in two columns. The 'Apply' button is highlighted with a red box, along with 'Cancel' and 'Help' buttons.


Step 2 Configure the other Access Point with reciprocal settings.



WDS with AP


The WDS mode converts the Access Point to a wireless bridge. It bridges the network clients from physically separate LANs into one virtual LAN and allows wireless clients to connect to the network via the Access Point.

Step 1 Select **WDS with AP** and enter the MAC address of the remote APs. Click **Apply** to save the changes.



The screenshot shows the configuration interface for the AIRLINK 101 networking solutions. The top navigation bar includes tabs for Primary Setup, System, Operating Mode, Access Control, Advanced Wireless, Setting Status, and Help. The 'Operating Mode' section is active, displaying the text: 'In this section you can change the operating mode of the 802.11g AP.' Below this, the 'Operating Mode' dropdown menu is set to 'WDS with AP'. A section for 'Remote AP MAC Address' contains eight input fields, numbered 1 through 8, arranged in two columns. The 'Apply' button is highlighted with a red box.

Step 2 Configure the other Access Point with reciprocal settings.



7.4 Access Control

The Access Control page allows you to control which PCs may or may not communicate with the Access Point depending on their MAC address.

AIRLINK 101 networkingsolutions **SUPER G Wireless Access Point**

Primary Setup System Operating Mode **Access Control** Advanced Wireless Setting Status Help

Access Control Please input the MAC address of each target workstation in order to Permit or Deny the connection to the network.

Access control:

Mac Address:

MAC Address Delete MAC Address Delete

Select **Accept** from the drop-down menu to enable Access Control.

AIRLINK 101 networkingsolutions **SUPER G Wireless Access Point**

Primary Setup System Operating Mode **Access Control** Advanced Wireless Setting Status Help

Access Control Please input the MAC address of each target workstation in order to Permit or Deny the connection to the network.

Access control:

Mac Address:

MAC Address Delete MAC Address Delete

Enter a **MAC Address**, then the **Save** button to create a list of PCs that can communicate with the AP.

Note: Each MAC address should be entered in this format: xxxxxxxxxxxx ("x" represents the actual characters of the MAC address).

Click **Apply** to save the changes.

If you want to block specific PCs from communicating with the Access Point, set Access Control to **Reject**. Enter a **MAC Address**, then click the **Save** button to create a list of PCs that cannot communicate with the AP.

The screenshot shows the AIRLINK 101 network management interface. The top navigation bar includes the AIRLINK 101 logo and a menu with options: Primary Setup, System, Operating Mode, Access Control (selected), Advanced Wireless, Setting Status, and Help. The main content area is titled "Access Control" and contains the following elements:

- A header: "Please input the MAC address of each target workstation in order to Permit or Deny the connection to the network."
- A label "Access control:" followed by a dropdown menu set to "Reject".
- A label "Mac Address:" followed by an empty text input field and a "Save" button.
- A row of buttons: "Apply", "Cancel", and "Help".
- A table with two columns: "MAC Address" and "Delete". The table is currently empty.

Note: Each MAC address should be entered in this format: xxxxxxxxxxxx ("x" represents the actual characters of the MAC address).

Click **Apply** to save the changes.

7.5 Advanced Wireless

The Advanced Wireless page allows you to customize data transmission settings. In most cases, the advanced settings on this page should remain at their default values.

Advanced Wireless! The Advanced Wireless settings should be left at their default values. Improper configuration may result in poor network performance.

Beacon Interval: (Default: 100, Milliseconds, Range: 20-1000)

RTS Length: (Default: 2346, Range: 256-2346)

Fragment Length: (Default: 2346, Range: 256-2346)

DTIM: (Default: 1, Range: 1-255)

Beacon Interval: The default value is **100**. Enter a value between 20 and 1000 milliseconds. The Beacon Interval value indicates the frequency interval of the beacon. A beacon is a packet broadcast by the Access Point to synchronize the wireless network.

RTS Threshold: This value should remain at its default setting of **2346**. The range is 256-2346 bytes.

Should you encounter inconsistent data flow, only minor modifications are recommended. If a network packet is smaller than the preset RTS threshold size, the RTS/CTS mechanism will not be enabled. The Access Point sends Request to Send (RTS) frames to a particular receiving station and negotiates the sending of a data frame. After receiving an RTS, the wireless station responds with a Clear to Send (CTS) frame to acknowledge the right to begin transmission.

Fragmentation Length: This value should remain at its default setting of **2346**. The range is 256-2346 bytes. It specifies the maximum size for a packet before data is fragmented into multiple packets. A smaller setting means smaller packets, which will create more packets for each transmission. Setting the Fragmentation Threshold too small may result in poor network performance. Only minor modifications of this value are recommended.

DTIM: The default value is **1**. This value, between 1 and 255 milliseconds, indicates the interval of the Delivery Traffic Indication Message (DTIM). A DTIM field is a countdown field informing clients of the next window for listening to broadcast and multicast messages. When the Access Point has buffered broadcast or multicast messages for associated clients, it sends the next DTIM with a DTIM Interval value. Its clients hear the beacons and awaken to receive the broadcast and multicast messages.

Click **Apply** to save the changes.

7.6 Setting Status

The Setting Status page displays the Access Point's current status and configuration. All information is read-only.

The screenshot shows the 'Setting Status' page of the AIRLINK 101 network management interface. The page has a blue header with the AIRLINK 101 logo on the left and 'SUPER G Wireless Access Point' on the right. Below the header is a navigation menu with buttons for 'Primary Setup', 'System', 'Operating Mode', 'Access Control', 'Advanced Wireless', 'Setting Status' (which is highlighted), and 'Help'.

The main content area is divided into sections. The 'Setting Status' section contains a description: 'This section contains setting information of the system.' Below this are two rows of configuration data:

- AP Name:** AP431W
- Firmware Version:** AP431W.v100.r541.t579-51

The 'LAN' section displays the MAC Address: 00:17:9a:b7:29:2b and a table of LAN configuration details:

Configuration Type	Manual
IP address:	192.168.1.250
Subnet Mask:	255.255.255.0
Default Gateway:	192.168.1.1


The 'Wireless' section displays the MAC Address: 00:17:9a:b7:29:2b and a table of wireless configuration details:

Operating Mode:	Normal AP
SSID:	default
Super G Mode:	Disabled
Channel:	6
Encryption Mode:	Open System / Encryption Disabled

At the bottom of the page, there are two buttons: 'Refresh' and 'Help'.

7.7 Help

The Help page provides links to online help files regarding each page of the Web Configuration Utility.



AIRLINK 101
networkingsolutions

SUPER G
Wireless Access Point

Primary Setup | *System* | *Operating Mode* | *Access Control* | *Advanced Wireless* | *Setting Status* | *Help*

Help This page provides you more detail information about following settings.

- [Primary Setup](#)
- [System](#)
- [Operating Mode](#)
- [Access Control](#)
- [Advanced Wireless](#)
- [Setting Status](#)

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Industry Canada Statement

This device complies with **RSS-210** of the Industry Canada Rules. Operation is subject to the following two conditions:

- 1) this device may not cause interference and
- 2) this device must accept any interference, including interference that may cause undesired operation of the device

This device has been designed to operate with an antenna having a maximum gain of **2dBi**.

Antenna having a higher gain is strictly prohibited per regulations of Industry Canada. The required antenna impedance is 50 ohms.

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the EIRP is not more than required for successful communication.

IMPORTANT NOTE:

IC Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Technical Support

E-mail: support@airlink101.com

Toll Free: 1-888-746-3238

Web Site: www.airlink101.com

* Super G™ technology (108Mbps) can only be obtained when using products with Atheros Super G™ chipset.

* Theoretical maximum wireless signal rate based on Atheros™ Super G™ and IEEE standard 802.11g specifications. Actual data throughput will vary. Network conditions and environmental factors, including volume of network traffic, building materials and construction, mix of wireless products used, radio frequency interference (e.g., cordless telephones and microwaves) as well as network overhead lower actual data throughput rate.

Copyright © 2007 AirLink101. All rights reserved. AirLink101, the stylized AirLink101 logo, specific product designations, and all other words and logos that are identified as trademarks and/or service marks are, unless noted otherwise, the trademarks and service marks of AirLink101. All other product or service names are the property of their respective holders. AirLink101 products are protected under numerous U.S. and foreign patents and pending applications, mask work rights, and copyrights.