Nighthawk® LTE Mobile Hotspot Router



רפל's קפל started

NETGEAR and Nighthawk are trademarks of NETGEAR, Inc. LTE is a trademark of ETSI. 4G LTE not available everywhere. Contains Lithium ion battery - recycle or displose of properly. ©2017 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks are the property of their respective owners.

Use the Nighthawk Mobile Router to Charge Other Devices

Give your smartphone or other device a boost by connecting to the mobile router's USB port. Battery boost begins automatically once the devices are connected.

What's in the Box?

- Nighthawk LTE Mobile Hotspot Router with pre-installed SIM card
- Bottom cover
- Battery
- Quick start guide
- USB Type-C cable
- AC adapter

LED Status

Slow blue blink Fast blue blink Slow amber blink

Ready for use. Transferring data. Not ready status.

For More Information

Manage Your Account

On the web: <u>att.com/my ATT</u>

Compatible device and online account required. Data and messaging rates may apply for download and app usage.

Need More Help?

On the web: att.com/DeviceHowTo

Or go to <u>http://attwifimanager/</u>, click the three dot icon **()** in the upper right corner.

Give Us a Call

611 from any AT&T wireless phone, or 800.331.0500. when prompted, enter your device's 10-digit number. (To get the number, go to <u>htto://attwifimanager</u> and click Dashboard.)



Connect Your Devices

1. Make sure that WiFi is enabled on the computer or mobile device and search for WiFi networks.

Windows	Click Internet Access (bottom right of your screen).
Мас	Go to the WiFi menu and select Network .
M. 1.11.	

- MobileGo to Settings and tap thedevicesWiFi icon.
- 2. Press and release **Power** button to view WiFi name and password.
- **3.** Select the WiFi name on the device that matches the name displayed on the mobile router screen.
- **4.** Enter the WiFi password as shown on the Nighthawk mobile router screen.
- **NOTE:** The password is case-sensitive.

Check SIM and Insert the Battery

1. Power off.



Power on Your Device

Turn on	Press and hold the Power button for three seconds.
Turn off	Press and hold the Power button for five seconds.
Wake	Press and quickly release the Power button.
Switch screens	Press and quickly release the Power button.

- 2. Check that the SIM card is firmly in place.
- **3.** Insert the battery.
- **4.** If you purchased an optional micro SD card (sold separately), insert the card into the micro SD slot.
- 5. Close the device with cover (included).
- **NOTE:** Open the cover by sliding the cover in the direction of the arrows on the cover until it clicks free.

Manage the Device on the Web

Change settings, view the device info, messages, and change features.

- Visit <u>http://attwifimanager/</u> or <u>http://192.168.1.1</u>.
- 2. Follow on-screen instructions.
- **3.** Change the default admin password for increased security.
- **4.** Log in using your admin password (default is attadmin), and click **Sign In**.

Manage settings using the NETGEAR mobile app.

- 1. Connect to the Internet.
- 2. Download the NETGEAR mobile app from <u>netgear.com/mobileapps</u>.

Upload and Share Files

Upload media files to a micro SD card or USB drive connected to the mobile router (both sold separately).

To upload media files using a computer:

- 1. Go to <u>http://attwifimanager</u> or <u>http://192.168.1.1</u> and log in with admin password.
- 2. Select Settings > Setup > Router Setup.
- 3. Select the Charge Only option from User USB port for under Tethering.
- 4. Click the MyMedia tab.
- 5. Drag and drop the files onto the page.