


User Manual



ANDROID DONGLE


iPPea Android Thumb PC Jump Start Guide

1. Product Overview




1. **USB HOST:** for USB peripherals and wireless mouse;
2. **USB OTG:** Micro USB with OTG function for other peripherals;
3. **System reset:** System reset button;
4. **Micro SDHC slot:** Micro SDHC card slot (Max 32GB);
5. **Hdmi:** HDMI plug to TV set;
6. **DC:** 5V DC socket;
7. **LED:** Power indicator;

2. **Micro SDHC card:** The maximum capacity is 32GB. It can store more photos, music, high definition video and playback on TV;




3. **OTG:** Through OTG cable, it can connect to OTG hub for other OTG USB peripherals such as camera hard disk and etc;



2. Operations

1. Insert the ipPea into the HDMI socket of the TV while power off ;



2. Take the USB DC power cable and insert the square end to the TV USB socket or external 5V DC power source. Plug the round needle end into the ipPea ;

OS	Android 4.0.3
CPU	XBurst 1.2Ghz
Graphics	3D graphic accelerator OpenGL ES 1.1&2.0
RAM	512MB DDR2
Storage	2GB Nand Flash Micro SD slot up to 32GB
Wireless	802.11 b/g/n
Display out	HDMI output up to 1080P
Features	Support USB OTG and USB HOST
Attachment	USB Power Cable; Micro USB Cable

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.