



**DSL-N10****Wireless ADSL Gateway**


**NOTE:** For more details and advanced configuration instructions, refer to the user manual included in the Utility CD.

EC Declaration of Conformity	
We, the undersigned,	ASUSTek COMPUTER INC. Inspiring Innovation · Persistent Perfection
Manufacturer:	ASUSTek COMPUTER INC.
Address, City:	No. 150, LI-TE RD., PEITOU, TAIPEI 112, TAIWAN R.O.C.
Country:	TAIWAN
Authorized representative in Europe:	ASUS COMPUTER GmbH
Address, City:	HARKORT STR. 21-23, 40880 RATINGEN
Country:	GERMANY
declare the following apparatus:	
Product name :	Wireless ADSL Gateway
Model name :	DSL-N10
conform with the essential requirements of the following directives:	
2004/108/EC-EMC Directive	
<input type="checkbox"/> EN 55022:2006+A1:2007	<input type="checkbox"/> EN 55024:1998+A1:2001+A2:2003
<input type="checkbox"/> EN 61000-3-2:2006+A2:2009	<input type="checkbox"/> EN 55020:2007
<input type="checkbox"/> EN 61000-3-3:2008	<input type="checkbox"/> EN 55013:2001+A1:2003+A2:2006
1999/5/EC-R & TTE Directive	
<input type="checkbox"/> EN 300 328 V1.7.1/2006-10	<input type="checkbox"/> EN 301 489-1 V1.8.1(2008)
<input type="checkbox"/> EN 300 440-1 V1.4.1/2008-05	<input type="checkbox"/> EN 301 489-3 V1.4.1/2002-08
<input type="checkbox"/> EN 300 440-2 V1.2 (2008-03)	<input type="checkbox"/> EN 301 489-4 V1.3.1/2002-08
<input type="checkbox"/> EN 301 511 V9.0.2/2003-03	<input type="checkbox"/> EN 301 489-7 V1.3.1(2005-11)
<input type="checkbox"/> EN 301 908-1 V3.2 (2007-05)	<input type="checkbox"/> EN 301 489-9 V1.4.1(2007-11)
<input type="checkbox"/> EN 301 908-2 V3.2 (2007-05)	<input type="checkbox"/> EN 301 489-17 V2.1.1(2009)
<input type="checkbox"/> EN 301 893 V1.4.1(2005-03)	
2006/95/EC-LVD Directive	
<input type="checkbox"/> EN 60950-1:2001+A11:2004	<input type="checkbox"/> EN 60065:2002+A1:2006
<input type="checkbox"/> EN 60950-1:2006	<input type="checkbox"/> EN 60950-1:2006+A11:2009
2009/125/EC-ErP Directive	
Regulation (EC) No. 1275/2008	Regulation (EC) No. 278/2009
<input type="checkbox"/> EN 62301:2005	<input type="checkbox"/> EN 62301:2005
<input type="checkbox"/> EN 62301:2005	
CE marking	
(EC conformity marking)	
Position : CEO	
Name : Jerry Shen	
Declaration Date: Jan. 03, 2011	
Year to begin affixing CE marking: 2011	
Signature : _____	

### 1. Connect your devices.



### 2. Before starting ADSL setting procedure, ensure that the ADSL indicator on DSL-N10 front panel become solid.



### 3. Launch the web browser and follow the Quick Internet Setup (QIS) steps.



**NOTE:** If the QIS web page does not appear after you launched the web browser, disable the proxy settings on the web browser.

### 4. Setup is completed.



## Setting up a Home Network

**English**

- 1. Connect your devices.
- 2. Before starting ADSL setting procedure, ensure that the ADSL indicator on DSL-N10 front panel become solid.
- 3. Launch the web browser and follow the Quick Internet Setup (QIS) steps.
  - \* If the QIS web page does not appear after you launched the web browser, disable the proxy settings on the web browser.
- 4. Setup is completed.

**Ukrainian**

- Підключіть пристрій.
- Перш ніж почнати процедуру налаштування ADSL, будь ласка, переконайтеся, що індикатор ADSL на панелі DSL-N10 не блимає.
- Запустіть браузер і дотримуйтесь інструкції для Швидкого з'єднання з мережею Інтернет (QIS).
  - \* Якщо веб-сторінка QIS не з'являється після того, як Ви запустили веб-браузер, вимкніть налаштування proxy веб-браузера.
- Налаштування завершено.

**French**

- Connectez les périphériques.
- Avant de configurer votre connexion ADSL, assurez-vous que l'indicateur ADSL du DSL-N10 est allumé.
- Lancez votre navigateur Web puis suivez les étapes du gestionnaire de configuration rapide d'Internet en ligne (QIS).
  - \* Si la page Web de QIS ne s'affiche pas lorsque vous lancez le navigateur Internet, désactivez les paramètres proxy du navigateur Internet.
- La configuration est terminée.

**Estonian**

- Ühendage seadmest.
- Enne ADSL-i seadistusprotseduuri käivitamist veenduge, et ADSL-i indikaator DSL-N10 paneelil oleks valmis.
- Käivitage veebibrauser ja järgige viisardi Quick Internet Setup (Interneti-ühenduse kiirhäälestust (QIS)) samme.
  - \* Kui pärast veebibrauseri käivitamist QIS'i veebleile ei ilmu, siis keelake veebibrauseri pöörihäälestust.
- Häälestus on lõpule viidud.

**Hungarian**

- Csatlakoztassa az eszközöket.
- Mielőtt hozzájön a QIS oldalhoz, győződjön meg arról, hogy a DSL-N10 előlapján lévő ADSL kijelző nem villog.
- Inditsa el a webböngészőt, és kövesse a gyors internetes beállítás (QIS) lépéseit.
  - \* Ha a QIS weblap nem jelenik meg a böngészőprogram indítása után, tiltsa le a proxy beállításait.

**Slovak**

- Pripojte svoje zariadenia.
- Skôr, ako spustíte postup nastavenia ADSL skontrolujte, či indikátor ADSL na paneli DSL-N10 svieti neprerušované.
- Spusťte internetový prehliadač a postupujte podľa krokov Stručného návodu pre nastavenie internetu (QIS).
  - \* Pokiaľ sa webová stránka QIS nezobrazí po spustení internetového prehliadača, deaktivujte proxy nastavenia internetového prehliadača.
- Nastavenie je dokončené.

**Czech**

- Připojte zařízení.
- Před zahájením postupu nastavení ADSL zkontrolujte, zda indikátor ADSL na předním panelu zařízení DSL-N10 svítí.
- Spusťte webový prohlížeč a postupujte podle kroků Rychlého nastavení Internetu (QIS).
  - \* Pokud se po spuštění webového prohlížeče nezobrazí webová stránka QIS, deaktivujte nastavení proxy webového prohlížeče.
- Instalace je dokončena.

**Finnish**

- Kytkke laitteet.
- Ennen ADSL-asetusproseduurin käynnistämistä varmista, että ADSL-ilmaisin DSL-N10:llä paneelia svetti seuraavasti.
- Spusțte internetový prehliadač a postupujte podľa krokov Stručného návodu pre nastavenie internetu (QIS).
  - \* Jos QIS-verkkosivu ei tule näkyviin verkkoselaimen käynnistämisen jälkeen, ota verkkoselaimen proxy-asetus pois päältä.
- Asennus on valmis.

**Dutch**

- Sluit uw apparaten aan.
- Voordat u begint met het instellen van de ADSL, moet u controleren of de ADSL-indicator op het DSL-N10 van het paneel stabiel brandt.
- Start de webbrowser en volg de QIS-stappen (Quick Internet Setup (snelle internetinstelling)).
  - \* Als de QIS-webpagina niet verschijnt nadat u de webbrowser hebt gestart, moet u de proxy-instellingen van de webbrowser uitschakelen.
- De instelling is voltooid.

**Bulgarian**

- Свържете устройствата.
- Пред да стартирате процедурата по настройка на ADSL, уверете се, че ADSL индикаторът на DSL-N10 от панела свети непрекъснато.
- Стартрайте уеб браузър и следвайте стъпките в Quick Internet Setup (QIS) (Бързи интернет настройки).
  - \* Ако уеб сайт QIS не се появява след като сте стартирали уеб браузъра, деактивирайте настройките на прокси сървър и уеб браузъра.
- Конфигурирането е завършено.

**Polish**

- Podłącz swoje urządzenia.
- Przed uruchomieniem procedury ustawień ADSL upewnij się, że świeci stałym światłem wskaźnik ADSL na panelu przednim DSL-N10.
- Uruchom przeglądarkę internetową i postępuj zgodnie z poleceńami Szybkiej konfiguracji Internetu (QIS).
  - \* Jeżeli strona sieciowa QIS nie jest wyświetlana po uruchomieniu przeglądarki sieciowej, należy wyłączyć ustawienia proxy przeglądarki sieciowej.
- Konfiguracja została zakończona.

**Spanish**

- Conecte sus dispositivos.
- Antes de iniciar el procedimiento de configuración de la conexión ADSL, asegúrese de que el indicador ADSL situado en el panel del router DSL-N10 se encuentre encendido.
- Abra su explorador web y siga los pasos indicados por la función Quick Internet Setup rápida de Internet.
  - \* Si la página web de QIS no aparece tras abrir el explorador web, deshabilite la configuración proxy del explorador web.
- Ha finalizado la configuración.

**Indonesian**

- Sambungkan perangkat.
- Sebelum memulai prosedur pengaturan ADSL, pastikan indikator ADSL pada DSL-N10 dari panel berwarna terang.
- Aktifkan browser Web, kemudian ikuti langkah-langkah Quick Internet Setup (QIS).
  - \* Jika halaman web QIS tidak muncul di layar setelah Anda mengaktifkan browser Web, nonaktifkan pengaturan proxy browser Web Anda.
- Konfigurasi selesai.

**Thai**

- เตรียมต่ออุปกรณ์ของคุณ
- ก่อนจะเริ่มกระบวนการตั้งค่า ADSL โปรดแน่ใจว่าสัญญาณ ADSL บน DSL-N10 บนแผงหน้าต้องดีด้วย
- เปิดเบราว์เซอร์ และท่านสามารถเชื่อมต่อได้แล้ว
- \* ถ้าหน้าจอ QIS ไม่ปรากฏขึ้นหลังจากที่คุณตั้งค่าเบราว์เซอร์
  - \* ให้มีการตั้งค่า proxy ของเบราว์เซอร์
- การตั้งค่าเสร็จสมบูรณ์

**Malaysian**

- Sambungkan peranti anda.
- Sebelum memulakan prosedur tetapan ADSL, sila pastikan penunjuk ADSL pada DSL-N10 dari panelnya menjadi padu.
- Lancarkan penyemak imbas web dan ikut langkah-langkah Persediaan Internet Pantas (QIS).
  - \* Jika laman web QIS tidak muncul setelah anda melancarkan web browser, memerlukan tetapan praksi pada web browser.
- Persediaan selesai.

## Notices

### ASUS Recycling/Takeback Services

ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for you to be able to responsibly recycle our products, batteries, other components, as well as the packaging materials. Please go to <http://csr.asus.com/english/Takeback.htm> for the detailed recycling information in different regions.

### REACH

Complying with the REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) regulatory framework, we published the chemical substances in our products at ASUS REACH website at <http://csr.asus.com/english/REACH.htm>

### Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**WARNING:** Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### FCC/Canada Radiation Exposure Statement

This equipment complies with FCC/Canada radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum 20cm between the radiator and your body.

### IC Warning Statement

This device had been designed to operate with the antennas for a maximum gain 5dBi, antenna type: dipole.

Antennas not described as above are strictly prohibited for use with this device.

This device complies with RSS-210 of the Industry Canada Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Ce dispositif est conforme à la norme CNR-210 d'Industrie Canada applicable aux appareils radio exempts de licence. Son fonctionnement est sujet aux deux conditions suivantes: (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

### NOTICES:

- This equipment meets the applicable Industry Canada Terminal Equipment Technical Specifications. This is confirmed by the registration number. The abbreviation, IC, before the registration number signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment.

- The Ringer Equivalence Number (REN) for this terminal equipment is **01**. The REN assigned to each terminal equipment provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed five.

### AVIS:

- Le présent matériel est conforme aux spécifications techniques d'Industrie Canada applicables au matériel terminal. Cette conformité est confirmée par le numéro d'enregistrement. Le sigle IC, placé devant le numéro d'enregistrement, signifie qu'enregistrement s'est effectué conformément à une déclaration de conformité et indique quelles spécifications techniques d'Industrie Canada ont été respectées. Il n'implique pas l'Industrie Canada a approuvé le matériel.
- L'indice d'équivalence de la sonnerie (IES) du présent matériel est de **01**. L'IES assigné à chaque dispositif terminal indique le nombre maximal de terminaux qui peuvent être raccordés à une interface téléphonique. La terminaison d'une interface peut consister en une combinaison quelconque de dispositifs, à la seule condition que la somme d'indices d'équivalence de la sonnerie de tous les dispositifs n'excède pas 5.

### FCC REQUIREMENTS

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the base unit of this equipment is a label that contains, among other information, a product identifier in the format US: **ASUDL01BDSL10**. If requested, this number must be provided to the telephone company.

The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company. For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format US: **ASUDL01BDSL10**. The digits represented by **01** are the REN without a decimal point (e.g., 03 is a REN of 0.3). For earlier products, the REN is separately shown on the label.

If your equipment causes harm to the telephone network, the telephone company may discontinue your service temporarily. If possible, they will notify you in advance. But if advance notice is not practical, you will be notified as soon as possible. You will be informed of your right to file a complaint with the FCC. Your telephone company may make changes in its facilities, equipment, operations or procedures that could affect the proper functioning of your equipment. If they do, you will be notified in advance to give you an opportunity to maintain uninterrupted telephone service.

If you experience trouble with this telephone equipment, please contact the following address and phone number for information on obtaining service or repairs. The telephone company may ask that you disconnect this equipment from the network until the problem has been corrected or until you are sure that the equipment is not malfunctioning. This equipment may not be used on coin service provided by the telephone company. Connection to party lines is subject to state tariffs.

Company: ASUS Computer International  
Address: 800 Corporate Way, Fremont, California 94539, USA  
Tel no.: +1-510-739-3777

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

### Declaration of Conformity for R&TTE directive 1999/5/EC

Essential requirements – Article 3

Protection requirements for health and safety – Article 3.1a

Testing for electric safety according to EN 60950-1 has been conducted. These are considered relevant and sufficient.

Protection requirements for electromagnetic compatibility – Article 3.1b

Testing for electromagnetic compatibility according to EN 301 489-1 and EN 301 489-17 has been conducted. These are considered relevant and sufficient.

Effective use of the radio spectrum – Article 3.2

Testing for radio test suites according to EN 300 328-2 has been conducted. These are considered relevant and sufficient.

### CE Mark Warning

This is a Class B product, in a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

Operation Channels: Ch1~11 for N. America, Ch1~14 Japan, Ch1~13 Europe (ETSI)

## Hot Products

### RT-N16

- Gigabit WAN and LAN with excellent routing speed
- Supports up to 300,000 sessions, perfect for P2P download
- Powerful CPU within provides the muscle for multitasking
- USB storage
- Supports NTFS read/write file system



### RT-N13U

- 802.11n draft 2.0 certified, fully compatible with 802.11b/g
- SuperSpeedN up to 300Mbps data rate, suitable for seamless multimedia stream
- EZConfig - WPS and WCN let any user setup secure Wi-Fi network within minutes
- EZQoS (Quality of Service)- Powerful and easily-operated bandwidth management engine streamlines your Gaming/Audio/Video experience
- EZ UI - Auto detection, no more setup
- USB application: share hard drive and AIO printer via USB 2.0
- Hardware switch: change operation mode intuitively.



### RT-N12

- ASUS EZUI with Auto detection, Network Map, Dr. Surf and ZQoS
- 300Mbps wireless speed and delivers 450% more signal coverage than 802.11g
- Provides three more virtual wireless router with bandwidth and access control
- Power by Broadcom BroadRange TM technology



### RT-N10

- ASUS EZUI with Auto detection, Network Map, Dr. Surf and ZQoS
- 150Mbps wireless speed and delivers 300% more signal coverage than 802.11g
- Provides one more virtual wireless router with bandwidth and access control
- Power by Broadcom Accelerange TM technology

### Manufacturer

#### ASUSTeK Computer Inc.

Tel: +886-2-2894-3447

Address: No. 150, LI-TE RD., PEITOU, TAIPEI 112, TAIWAN

### Authorised representative in Europe

#### ASUS Computer GmbH

Address: HARKORT STR. 21-23, 40880 RATINGEN, GERMANY

### Authorised distributors in Turkey

#### BOGAZICI BIL GISAYAR SAN. VE TIC. A.S.

Tel: +90 212 3311000

Address: AYAZAGA MAH. KEMERBURGAZ CAD. NO.10 AYAZAGA/ISTANBUL

#### CIZGI Elektronik San. Tic. Ltd. Sti.

Tel: 0090 212 3567070

Address: CEMAL SURURI CD. HALIM MERIC IS MERKEZI No:15/C D: 5-6 34394

MECIDIYEKOY/ISTANBUL

EEE Yönetmeliğine Uygundur.

## Networks Global Hotline Information

Area	Hotline Number	Support Languages	Working Hour	Working Day
Australia	1300-2787-88	English	9:00-18:00	Mon. to Fri.
Austria	0043-820240513	German	9:00-18:00	Mon. to Fri.
Belgium	0032-78150231	Dutch /French	9:00-17:00	Mon. to Fri.
China	800-820-6655; 021-34074610	Simplified Chinese	9:00-18:00	Mon. to Sun.
Denmark	0045-3832-2943	Danish/English	9:00-17:00	Mon. to Fri.
Finland	00358-9693-7969	Finnish/English/Swedish	10:00-18:00	Mon. to Fri.
France	0033-170949400	France	9:00-17:45	Mon. to Fri.
Greece	00800-44-14-20-44	Greek	9:00-13:00; 14:00-18:00	Mon. to Fri.
Hong Kong	3582-4770	Cantonese/Chinese/English	10:00-20:00	Mon. to Fri.
Ireland	0035-31890719918	English	9:00-17:00	Mon. to Fri.
Japan	0800-213-2787	Japanese	9:00-17:00	Sat. to Sun.
Malaysia	+603 2148 0827 (Check Repair Detail Status Only) +603-6279-5077	Bahasa Melayu/English	10:00-19:00	Mon. to Fri.
Netherlands / Luxembourg	0031-591-570290	Dutch / English	9:00-17:00	Mon. to Fri.
New Zealand	0800-278-788 / 0800-278-778	English	9:00-17:00	Mon. to Fri.
Norway	0047-2316-2682	Norwegian /English	9:00-17:00	Mon. to Fri.
Philippines	+63-638-8504; 1800-1410573	English	9:00-18:00	Mon. to Fri.
Poland	00225-718-033; 00225-718-040	Polish	8:30-17:30	Mon. to Fri.
Portugal	707-500-310	Portuguese	9:00-17:00	Mon. to Fri.
Russia	+8-800-100-ASUS; +7-495-231-1999	Russian/ English	9:00-18:00	Mon. to Fri.
Singapore	+65-6720-3835 (Check Repair Detail Status Only) +65221701	English	11:00-19:00	Mon. to Fri.
Slovak	00421-232-162-621	Czech	8:00-17:00	Mon. to Fri.
Spain	902-88-96-88	Spanish	9:00-18:00	Mon. to Fri.
Sweden	0046-6587-6940	Swedish/ English	9:00-17:00	Mon. to Fri.
	0041-84811010	German/French	9:00-18:00	Mon. to Fri.
Switzerland	0041-84811014	French	9:00-17:45	Mon. to Fri.
	0041-84811012	Italian	9:00-17:00	Mon. to Fri.
Taiwan	0800-093-456; 02-81439000	Traditional Chinese	9:00-12:00; 13:30-18:00	Mon. to Fri.
Thailand	+662-679-8367-70; 001 800 852 5201	Thai/English	9:00-18:00	Mon. to Fri.
Turkey	+90-216-524-3000	Turkish	09:00-18:00	Mon. to Fri.
United Kingdom	0044-870-1208340; 0035-31890719918	English	9:00-17:00	Mon. to Fri.
USA/Canada	1-812-282-2787	English	8:30am-12:00pm EST (5:30am-9:00pm PST)	Mon. to Fri.
			9:00am-6:00pm EST (6:00am-3:00pm PST)	Sat. to Sun.

Visit ASUS website for more information: <http://support.asus.com>